
30
49
14
16
10

PARTS CATALOG

Mole-Richardson Co.

TABLE OF CONTENTS

Type	Description	Page
Type 2351	Midget Solarspot®	1-3
Type 2581	Molequartz® Baby Softlite	5-7
Type 2591	Molequartz® 2K Baby “Zip” Softlite	9-10
Type 2801	Mini-Mole Solarspot®	11-13
Type 2831	Baby-Baby Solarspot®	15-18
Type 2901	Tiny-Mole®	19-22
Type 2921	Molequartz® 1K Nooklite	23-25
Type 3081	6” Baby Cool Red®	27-30
Type 3101	Inbetweenie Solarspot®	31-33
Type 3131	Betweenie®	35-39
Type 4031	Molequartz® Teenie Weenie	41-44
Type 4051	Teenie-Mole®	45-49
Type 407	Baby Solarspot®	51-54
Type 4081	Mickey-Mole®	55-58
Type 4091	Mighty-Mole®	59-62
Type 4181	Baby Tener Solarspot®	63-67
Type 4191	Baby Senior Solarspot®	69-73
Type 4251	Molequartz® Solarspot®	75-77
Type 4821	Baby Solarspot®	79-83
Type 5291	8” Junior Cool Redhead®	85-89
Type 5761	6 Light Molequartz® Molepar®	91-93
Type 5771	9 Light Molequartz® Molepar®	95-97
Type 2821	Molequartz® Tweenie-Mole Solarspot®	99-100
Type 4821	Molequartz® Tweenie II Solarspot®	101-102
Type 2831	Molequartz® Baby-Baby Solarspot®	103-104
Type 4131	Molequartz® Baby Junior Solarspot®	105-106
Type 4281	Molequartz® 8” Junior Solarspot®	107-110
Type 4191	Molequartz® Baby Senior Solarspot®	111-112
Type 4181	Molequartz® Baby Tener Solarspot®	113-114
Type 2901	Tiny-Mole Solarspot®	115
Type 2801	Mini-Mole Solarspot®	117-118
Type 2351	Midget Solarspot®	119-120
Type 407	Baby Solarspot®	121-124
Type 412	Junior Solarspot®	125-128
Type 415	Senior Solarspot®	129-130
Type 416	Tener Solarspot®	131-132
Type 416	Tener Solarspot®	131-132
Type 4241	“Big Eye” Tener Solarspot®	133-134
Type 4031	Molequartz® Teenie Weenie Mole	135-136
Type 4051	Molequartz® Teenie-Mole	137
Type 4081	Molequartz® Mickey-Mole	139
Type 4091	Molequartz® Mighty-Mole	141
Type 3311	Molequartz® 1K Molette	143
Type 3321	Molequartz® 2K Molette	145
Type 2911	Molequartz® One-Light Nooklite	147
Type 2921	Molequartz® 1K Nooklite	149
Type 2941	Molequartz® 2K Nooklite	151
Type 2931	Molequartz® Three-Light Nooklite	153
Type 2981	Molequartz® Mini-Softlite	155
Type 2581	Molequartz® Baby Softlite	157
Type 2591	Molequartz® 2K Baby “Zip®” Softlite	159
Type 3571	Molequartz® 4K Baby Softlite	161
Type 2551	Molequartz® Super-Softlite	163
Type 2561	Molequartz® Super-Softlite	165
Type 2571	Molequartz® Super-Softlite	167
Type 2621	Molequartz® Super-Softlite	169-170
Type 8142	Molequartz® 14” Fixed Focus Scoop	171
Type 8182	Molequartz® 18” Fixed Focus Scoop	172
Type 8141	Molequartz® 14” Focusing Scoop	173
Type 8181	Molequartz® 18” Focusing Scoop	174
Type 3211	Molequartz® Broad	175-176
Type 3221	Molequartz® Double Broad	177-178
Type 3401	Molequartz® Super-Broad	179

TABLE OF CONTENTS

Type	Description	Page
Type 5711	Molequartz® One-Light Molefay®	181
Type 5721	Molequartz® Two-Light Molefay®	182
Type 5581	Molequartz® Four-Light Molefay®	183
Type 5591	Molequartz® Six-Light Molefay®	184
Type 5541	Molequartz® Nine-Light Molefay®	185
Type 5571	Molequartz® Twelve-Light Molefay®	186
Type 2271	Molequartz® Molepar®	187
Type 4711	Molequartz® One-Light Molecool®	189
Type 5891	Molequartz® Nine-Light Molecool®	191
Type 245	Skylite	193
Type 16	Cinelite	195
Type 1000	Bell Lamp	197
Type 8011	Molequartz® Molelipso®	199-201
Type 8014	and 8016 Accessory Lens Assemblies	202
Type 8012	and 80112 Accessory Iris Assemblies	203
Type 8021	Molequartz® Molelipso®	205-207
Type 8026	Accessory Lens Assemblies	208
Type 8028	Accessory Lens Assemblies	208
Type 8022	Accessory Iris Assemblies	209
Type 80212	Accessory Iris Assemblies	209
Type 1963	Fogmaker Moleffect®	211-215
Type 1971	Windmachine Moleffect®	217-220
Type 5601	Molepac Stand (1/2” Tube)	221
Type 5602	Molepac Stand (3/8” Tube)	222
Type 5603	Molepac Stand (5/8” Spud)	223
Type 1391	Baby Size Low Stand	225
Type 40651A	(Standard) Baby Size Pedestal	227
Type 1581	Baby Size Sky-Hi Stand	229
Type 1561	Junior Size Sky-Hi Stand	230
Type 1851	Baby Size Sky-Hi Litewate Stand	231
Type 2541	Baby Size Compact Litewate Stand	232
Type 3281	Baby Size Litewate Stand	233
Type 410138	Junior Size Pedestal (Standard)	235
Type 500557	Junior Size Litewate Location Stand	237
Type 500791	Junior Size Sky-Hi Litewate Location Stand	238
Type 1411	Junior Size Low Stand	239
Type 41475	(Single Lift) Senior Size Stand	241
Type 41494	(Double Lift) Senior Size Stand (Standard)	242
Type 500476	Junior Size Litewate Standard Stand	243
Type 1571	Senior Size Sky-Hi Stand	245
Type 418181	Senior Size Litewate Low Stand	247
Type 418182	Senior Size Litewate Standard Stand	248
Type 418183	Senior Size Litewate Sky-Hi Stand	249
Type 5611	Senior Size Long Leg Stand	251
Type 3441	Low Aluminum Moleflector® Stand	253
Type 3163	Medium Roller Folding Stand	255
Type 500572	Folding Crank-Up Litewate Stand	257-258
Type 325	Molevator®	259-264
Type 103B	Microphone Boom and 126B Perambulator	265-281
Type 75	Comet Lamp Boom	283
Type 24	Century Head	285
Type 324	Century Stand	286
Type 3143	Standard Century Stand	287
Type 3153	Medium Century Stand	288
Type 3144	Century Single Arm Head	289
Type 3154	Medium Century Single Arm Head	290
Type 3145	Century Double Arm Head	291
Type 3155	Medium Century Double Arm Head	292
Type 3166	Clamp Head	293
Type 50	Half Stage Plug (Not Fused)	295
Type 50F2	Half Stage Plug (Fused)	297
Type 100A	Full Stage Plug	299

PARTS FOR TYPE 2351
MIDGET SOLARSPOT ®



Mole-Richardson Co.

PARTS FOR TYPE 2351
MIDGET SOLARSPOT ®


h726
235–16
h029
h198
235–17
235–14
400–91
235–10
h422
235–18
404–18a
235–15
h1203
h196
h029
235–13
kn0b
h187
h028
235–19
cd05
h196
h029
h118
h132
555–117
235–12
235–47
407–44
be12
235–78
235–21
h068
235–11
h034
h615
500–20c
235–5

PARTS FOR TYPE 2351
MIDGET SOLARSPOT ®


h1747
h009
500–1584
400–16
500–1585
500–1583
*400–91
500–1582

*Complete switch & cable

4

PARTS FOR TYPE 2581
750 WATT MOLEQUARTZ ® BABY SOFTLITE



PARTS FOR TYPE 2581
750 WATT MOLEQUARTZ ® BABY SOFTLITE


258–16
h870
h133
258–15
h744
258–14
258–8
258–3
sk19
h616
h034
h068
206–24
750–65
be12
500–16
500–20c
406–66
406–63

PARTS FOR TYPE 2581
750 WATT MOLEQUARTZ ® BABY SOFTLITE


500–1584
* 400–92
400–16
500–1585
500–1583

*Complete switch & cable assembly

PARTS FOR TYPE 2591
2,000 WATT MOLEQUARTZ® 2K BABY "ZIP" SOFTLITE



PARTS FOR TYPE 2591
2,000 WATT MOLEQUARTZ® 2K BABY "ZIP" SOFTLITE



h870
259-18
259-26
258-14
h309
256-8
h744
259-33
h009
h133
259-27
259-62
13" lead
259-39
400-39
259-61
5" lead
sw14
259-28
h615
h068
h034
400-16
206-24
557-42
259-38
500-20cp
be12
259-20
500-571
406-63

PARTS FOR TYPE 2801
MINI-MOLE SOLARSPOT®



PARTS FOR TYPE 2801
MINI-MOLE SOLARSPOT®


2803
280–16
h1137
h134
280–2
(h187)
280–9
404–18a
280–40
h1115
280–4
h1398
280–5
cd07
kn08
280–8
280–12
h1115
280–29
be04
h138
280–13p
h251
h882
280–10
280–13p
235–5

Serial No. 18,483
and above apply.

PARTS FOR TYPE 2801
MINI-MOLE SOLARSPOT®


*400-122
500-1584
400-16
500-1585
500-1583

*Complete switch & cable assembly

PARTS FOR TYPE 2831
BASY-BABY SOLARSPOT®



PARTS FOR TYPE 2831
BABY-BABY SOLARSPOT®



283-54
283-63
283-37
283-22
418-55
413-33
(h261)
283-65
(h200)
283-35
551-26
(h223)
(h323)
(h134)
283-66
283-43
283-36
(h133)
407-65
407-66
283-58
407-73
(h342)
407-70
407-68
413-95
283-60
(h200)
283-103
283-59
407-64
(h342)
(h342)
screw
(h311)
nut
(h133)
h1214

PARTS FOR TYPE 2831
BABY-BABY SOLARSPOT®


283-39
h310
283-42
283-33
283-33
cd05
283-21
283-19
ri12
283-93
h725
283-1p15
283-70
283-20
283-1p10
500-658
283-1p11
283-1p13
283-1p12
283-69
280-13p
406-63
283-20

PARTS FOR TYPE 2831
BABY-BABY SOLARSPOT®


* 400-35
500-26
(h342)
400-15
500-28
500-27

*COMPLETE SWITCH & CABLE ASSY.

PARTS FOR TYPE 2901
TINY- MOLE®



290 TINY - MOLE
200 WATTS SOLAR SPOT

PARTS FOR TYPE 2901
TINY- MOLE®


SWITCH/CABLE ASSY.
LAMP ASSY.
290-70
BE04
290-80
H594
H033
H067
283-69
290-72
280-13
235-7
YOKE ASSY.
COMPLETE BASE
PLATE ASSY.
P/N 235-5
235-6

PARTS FOR TYPE 2901
TINY- MOLE®


H311
280-3
290-63
280-16
H134
H1137
H009
BU05
H187 (2PL)
H008 (2PL)
290-62
H187 (2PL)
H008 (2PL)
H189
H132
KN08
H1398
H310 (4PL)
H009
H133
290-69
290-60
290-61
280-40
H310 (3PL)
290-59 (3PL)
290-50
290-24
290-67

LAMP ASSY.

PARTS FOR TYPE 2901
TINY- MOLE®



COMPLETE SWITCH BOX ASSY.
(500 - 1582)

SWITCH / CABLE ASSY.
(400 - 113)


INCLUDED WITH SWITCH (2PL)
H1747 (4PL)
H009 (4PL)
H1460
500–1584
400–16
CA41 (BOTH ENDS)
TR304
PL98
500–1585
500–1583

PARTS FOR TYPE 2921
1,000 WATT MOLEQUARTZ ® 1K NOOKLITE



PARTS FOR TYPE 2921
1,000 WATT MOLEQUARTZ ® 1K NOOKLITE


292-16
292-44
292-57
h233
292-14
292-9
sk19
h742
408-26
280-13
292-22
h595
h033
h066
h068
292-23
280-13
406-63

PARTS FOR TYPE 2921
1,000 WATT MOLEQUARTZ ® 1K NOOKLITE


500–26
400–15
500–28
500–27
* 400–32

*Complete switch & cable assembly

PARTS FOR TYPE 3081
6" Baby Cool Red®



PARTS FOR TYPE 3081
6" Baby Cool Red®


be12
500-568
h410
307-52
ri101
406-66
750-65
307-37
h313
ri101
307-42
500-20c
h616
h034
h068
206-24
413-84
h313
h744
406-63
407-14
h011
h349
407-12a
407-11
h344
ri101
307-36
h313
cp02
h135
cdo2
407-12a
407-14
h344
h011
h349
h313
h344
h1198
407-37
407-38
h349
407-39
h011
407-14
413-85
413-198

PARTS FOR TYPE 3081
6" Baby Cool Red®


407-229
407-231
h028
h299
407-227
551-26
283-106
283-35
h309
2ea.
h029
2ea.
551-26
h332
407-228
407-343
407-235
407-230
h010
2ea.
h818
2ea.
h326
2ea.

PARTS FOR TYPE 3081
6" Baby Cool Red®


406–26
407–45
407–98
(h029)
(h197)
(h137)
407–46
407–61
407–62
(h011)
(h011)
(h135)
(h266)
(h133)
(h135)
(h011)
(h881)
407–67
(h310)
407–236p23
(h1203)
(h312)
407–64
407–57 (focusing handle assembly)
(h199)
407–69
(h347)
407–57p5
(h1298)
(h133)
(h340)
407–236p23
(h1203)
407–63
(h133)
407–32
(h340)
400–10
407–73
407–66
407–65
407–70
407–68
407–72
407–236p27
(sw14)
407–377
(h311)
4ea.
407–60
(ri02) 4ea.
407–75
407–22
400–16
(h311)
4ea.
(ri09)
4ea.
407–74

PARTS FOR TYPE 3101
Inbetweenie Solarspot®



PARTS FOR TYPE 3101
Inbetweenie Solarspot®


310-52
H299
310-26
310-3
H299
310-24
H299
310-30
290-24
482-38
sp08
h1197
310-25
H299
482-37
310-31
H594
H067
H299
290-80
BE04
310-32
313-33
H0022
H033
313-52
310-29
500-20C

PARTS FOR TYPE 3101
Inbetweenie Solarspot®


H311
310-18
SK33
H299
310-20
310-19
310-27
H341
H031
h1398
KN03
H311
H309
H133
H009
310-28

PARTS FOR TYPE 3131
300 WATTS BETWEENIE®



313 BETWEENIE
300 WATTS LAMP ASSY

PARTS FOR TYPE 3131
300 WATTS BETWEENIE®



LAMP HEAD ASSY.
SWITCH/CABLE ASSY.
TROUGHT ASSY.
H063 (4PL)
H029 (4PL)
H313 (4PL)
H597
H033
H067
313-52
500-20C
290-80
BE04
313-24

YOKE ASSY.

PARTS FOR TYPE 3131
300 WATTS BETWEENIE®



H304 (2PL)
H028 (2PL)
SK14
313-28
H299 (2PL)
H028 (2PL)
BU07 (2PL)
H297
290-69
313-21
313-19
309-22
H1398 (2PL)
KN03 (2PL)
BU05
H341 (2PL)
H031 (2PL)
309-23

TROUGHT ASSY.

PARTS FOR TYPE 3131
300 WATTS BETWEENIE®


H029 (6PL)
H313 (6PL)
313-53
H029 (2PL)
H313 (2PL)
313-3
H029
H313
313-32
H029 (2PL)
H313 (2PL)
309-26 (2PL)
482-38
SP08
482-37
280-5
H313 (3PL)
H029 (3PL)
313-43 (3PL)
CD07
313-30
280-5
H029
H313
H313
H029
H313 (2PL)
H029 (2PL)
313-31
313-33 (2PL)
313-34

LAMP HEAD ASSY.

PARTS FOR TYPE 3131
300 WATTS BETWEENIE®



COMPLETE SWITCH BOX ASSY.
(500 - 1582)

SWITCH / CABLE ASSY.



INCLUDED WITH SWITCH (2PL)
H1747 (4PL)
H009 (4PL)
H1460
500–1584
PL98
400–16
CA41 (BOTHENDS)
TR304
500–1585
500–1583

PARTS FOR TYPE 4031
600 WATT MOLEQUARTZ®
TEENIE WEENIE



PARTS FOR TYPE 4031
600 WATT MOLEQUARTZ®
TEENIE WEENIE


408-31
h1400
403-46
h311
h009
403-27
e05
403-64
bu16
403-41
403-36
403-32
rn24
403-34
sk02
403-35

PARTS FOR TYPE 4031
600 WATT MOLEQUARTZ®
TEENIE WEENIE


h868
403-45
403-63
403-21
403-38
403-29
h009
h311
500-658
403-48
be04
h311
h009
h067
403-47
403-17
280-13

PARTS FOR TYPE 4031
600 WATT MOLEQUARTZ®
TEENIE WEENIE


500-1584
400-16
500-1585
500-1583
* 400-112

Complete switch & cable assembly

PARTS FOR TYPE 4051
TEENIE-MOLE®



405 TEENIE - MOLE ASSY.

PARTS FOR TYPE 4051
TEENIE-MOLE®


SWITCH/CABLE ASSY
LAMP HEAD ASSY.
408-26
H033
H066
H596
BE04
280-13 (2PL)
ACCESSORY HOLDER ASSY.
405-32
YOKE ASSY.
CABLE TIE UP CORD ASSY.
(406-63)

PARTS FOR TYPE 4051
TEENIE-MOLE®



REFLECTOR ASSY.
(405-26)


H1400
408-31
H341 (2PL)
H011 (2PL)
BU84
SK20
H1115 (4PL)
405-20
H133 (8PL)
H029 (8PL)
H1115 (2PL)
408-32
405-27
RI12 (2PL)
408-15 (2PL)
408-20
405-31
RN24
H304 (8PL)
405-28
405-63
H008 (2PL)
H300 (2PL)

LAMP HEAD ASSY.

PARTS FOR TYPE 4051
TEENIE-MOLE®


H869 (2PL)
H065 (2PL)
408-52
405-34
408-51

ACCESSORY HOLDER ASSY.


COMPLETE ACCESSORY HOLDER
ASSY. (405-5)

PARTS FOR TYPE 4051
TEENIE MOLE®



COMPLETE SWITCH BOX ASSY.
(500 -1582)

SWITCH / CABLE ASSY.


INCLUDED WITH
SWITCH (2PL)
H1747 (4PL)
H009 (4PL)
H1460
500–1584
PL98
400–16
CA41 (BOTH ENDS)
TR304
500–1585
500–1583

PARTS FOR TYPE 407
BABY SOLARSPOT®



PARTS FOR TYPE 407
BABY SOLARSPOT®


407–9p21
(be12)
407–44
(h410)
407–3p8
(dp04)
(ri02)
2ea.
750–65
413–60
(h313)
3ea.
(ri02)
407–30
500–20c
407–9p18
(h616)
407–9p19
(h034)
407–9p20
(h068)
206–24
407–12
(h313)
2ea.
(h744)
406–63
407–14
(h011)
(h344)
407–12a
407–11
(h344)
(ri02)
3ea.
413–61
(h313)
3ea.
cp02
h135
cd02
407–12a
407–14
(h344)
(h011)
(h348)
(h313)
2ea.
(h344)
(h348)
(h011)
407–14
(h1198)
407–37
407–38
407–39
407–13
413–196

PARTS FOR TYPE 407
BABY SOLARSPOT®


407-229
407-231
h028
h299
407-227
551-26
283-106
h309
2ea.
283-35
h029
2ea.
551-26
h332
407-228
407-343
407-235
407-230
h010
2ea.
h818
2ea.
h326
2ea.

PARTS FOR TYPE 407
BABY SOLARSPOT®



407-45
406-26
407-98
(h029)
(h197)
(h137)
407-46
407-61
407-62
(h011)
(h011)
(h135)
(h266)
(h133)
(h135)
(h011)
(h881)
407-67
(h310)
407-236p23
(h1203)
(h312)
407-64
407-57 (focusing handle assembly)
(h199)
407-69
(h347)
407-57p5
(h1298)
(h133)
(h340)
407-236p23
(h1203)
407-63
(h133)
407-32
(h340)
400-10
407-73
407-66
407-65
407-70
407-68
407-72
407-236p27
(sw14)
407-377
(h311)
4ea.
407-60
(ri02) 4ea.
407-22
407-75
400-16
(h311)
4ea.
(ri09)
4ea.
407-74

PARTS FOR TYPE 4081
Mickey-Mole®



PARTS FOR TYPE 4081
Mickey-Mole®


h1400
408-31
408-10
rn24
h1115
408-32
408-15
h394
408-23
408-20
sk20
h1115
408-62
280-13
be04
408-26
h067
h033
h596
280-13
406-63

PARTS FOR TYPE 4081
Mickey-Mole®


500-26
* 400-8
400-15
500-28
500-27

*Complete switch & cable assembly

PARTS FOR TYPE 4081
Mickey-Mole®


h869
h065
408-51
408-5
408-50
408-52
h869

PARTS FOR TYPE 4091
2,000 WATT MOLEQUARTZ ® MIGHTY-MOLE



Mole-Richardson Co.

PARTS FOR TYPE 4091
2,000 WATT MOLEQUARTZ ® MIGHTY-MOLE

parts for type 4091
mighty-mole®

order part number and quantity desired


409-27
409-20
h1400
h1115
409-37
409-71
408-31
RN 24
h394
409-27
409-29
409-36
sk20
409-31
206-24
h034
h068
h616
500-16p
be12
409-38
406-63
500-20cp

mole-richardson
937 north sycamore ave.
hollywood, ca. 90038
tel:(323) 851-0111 fax:(323) 851-5593 e-mail: info@mole.com www.mole.com

manufacturing · sales · rentals · studio depot · moletown
Mole-Richardson Co.

PARTS FOR TYPE 4091
2,000 WATT MOLEQUARTZ ® MIGHTY-MOLE


h869
h065
408–51
409–40
409–41
h065
h869
409–5

PARTS FOR TYPE 4091
2,000 WATT MOLEQUARTZ ® MIGHTY-MOLE


400–18
* 400–17
400–1
400–20
400–19

*Complete switch & cable assembly

PARTS FOR TYPE 4181
BABY TENER SOLARSPOT®



418

BABY TENER SOLAR SPOT

PARTS FOR TYPE 4181
BABY TENER SOLARSPOT®


LAMP HEAD ASSY.
418-7
TROUGHT ASSY.
418-8
H657
H042
H072
414-35
418-26
418-50
2 PL
418-25
BE09
500-570
H657
418-10 COMPLETE YOKE ASSY.
(LESS 424-73 & 414-68)
H042
418-20
H034
H614
424-73
414-68
YOKE ASSY.

PARTS FOR TYPE 4181
BASY TENER SOLARSPOT®


418-6
(LAMP HEAD SHEET METAL ASSY.)
DP01
418-30 (FRONT SPINNING)
H436
(4PL)
461-131
415-36
415-37
H011 (2PL)
H361 (2PL)
415-38
414-73
CD09
418-98
415-83 (3PL)
H011 (3PL)
H341 (3PL)
H011 (2PL)
H344 (2PL)
461-3
418-28
418-29
(REAR SPINNING) 418-35
H237
(8PL)
H135
418-36
(ON THE OTHER SIDE
418-37)
H344
H011 (3PL)
H135 (3PL)
H011
418-96
415-34
(2PL)
H344 (2PL)
H011 (2PL)
H011
(2PL)
CP02 (3PL)
H347 (3PL)
418-97 (3PL)
H344 (2PL)
H361 (2PL)
H011 (2PL)

LAMP HEAD ASSY.

PARTS FOR TYPE 4181
BASY TENER SOLARSPOT®


418-347
H135 (3PL)
H265 (3PL)
418-55 (3PL)
H011 (3PL)
H261 (3PL)
H779
418-34
414-39
415-140
415-61 (2PL)
418-42
(2PL)
418-18
416-31
H882
414-27A
H876
H577
418-16
418-17
418-247
CN10
H589
418-245
H1223
H1376
(2PL)
H344
418-82
H022
H137
H134 (2PL)
H010 (2PL)
H1501
460-146
418-57
418-43
H433 (2PL)
418-44
418-58
103B-163
H011 (2PL)
H135 (2PL)
H340 (2PL)
461-44 (2PL)
H135
H011
418-54
TR002
H330 (2PL)
H135 (2PL)
H011 (2PL)
418-90
H436 (2PL)
418-52
H011 (4PL)
H344 (4PL)
418-375
H011 (4PL)
H342 (4PL)
H011 (4PL)
H360 (4PL)
418-23
418-53 (2PL)
H436 (6PL)
H589 (4PL)
H011 (4PL)
H011 (2PL)
H011 (2PL)
H342 (2PL)
418-32
H1134 (4PL)
H014 (4PL)

TROUGH ASSY.

PARTS FOR TYPE 4181
BABY TENER SOLARSPOT®



FOCUSING SCREW ASSY.
(418 - 13)



MIRROR & SUPPORT ASSY.
(418 - 4)



SOCKET ASSY.
(418 - 18)



SWITCH ASSY.
(418 - 9)

PARTS FOR TYPE 4191
BABY SENIOR SOLARSPOT®



419
BABY SENIOR SOLAR SPOT

PARTS FOR TYPE 4191
BABY SENIOR SOLARSPOT®


LAMP HEAD ASSY.
419-2
TROUGH ASSY.
419-5
H011 (6PL)
H360 (6PL)
H636
H037
H070
410-52
2000-38
BE09
500-570
412-186
H654
H016
H614
H034
410-50
414-68
YOKE ASSY.

Mole-Richardson Co.

PARTS FOR TYPE 4191
BABY SENIOR SOLARSPOT®


H011 (4PL)
419-4
(LAMP HEAD SHEET METAL ASSY)
419-48
H436 (4PL)
H135 (4PL)
DP01
419-67 (FRONT SPINNING)
H135
419-71
H011 (2PL)
H360 (2PL)
407-38
419-73
CD03
H135 (3PL)
H734 (3PL)
H344 (3PL)
419-49
(REAR SPINNING) 419-68
H361 (8PL)
H011 (8PL)
410-128
(ON THE OTHER SIDE
410-129)
H344
H011
407-39
407-37
419-74 (3PL)
419-69
H011 (2 PL)
H360 (2PL)
H486 (3PL)
H029 (3PL)
407-98 (3PL)
412-31 (2PL)
CP02 (3PL)
429-52

HEAD ASSY.

PARTS FOR TYPE 4191
BABY SENIOR SOLARSPOT®


H277
H263 (2PL)
H031 (2PL)
H880 (2PL)
H031
H880
H880
H278
220-14
H265 (3PL)
H031 (3PL)
413-130
412-167 (2PL)
220-14A
412-170
419-66
413-100
H389
H265 (3PL)
H135 (3PL)
419-16
419-15
418-55 (3PL)
H011 (3PL)
H261 (3PL)
CP01
H011
H135
H265 (2PL)
H031 (2PL)
H267
H881 (2PL)
220-19
4419-65
400-80
412-35
419-35
H031
H135
H266
412-18
H1158
H1200
419-42
H013
412-21
H137
H033
H067
419-40
419-41
H013
419-53
H011
H343
419-29
CN07
H758
419-64 (2PL)
H011
CP01
419-382
412-47
419-38
419-11
H010 (2PL)
H323 (2PL)
412-46
H1215
419-87
LU97
419-78
H342 (4PL)
415-46
H011
H360
419-37
419-36
H433 (4PL)
419-44 (2PL)
419-54
412-29
H343
H011

TROUGH ASSY.

PARTS FOR TYPE 4191
BABY SENIOR SOLARSPOT®



419 - 6 ASSY.



413 - 53 ASSY.



419 - 78 ASSY.



419 - 7 ASSY.



400 - 80 ASSY.

PARTS FOR TYPE 4251
20,000/24,000 WATT MOLEQUARTZ SOLARSPOT®

LAMP ASSEMBLY

FRONT VIEW



REAR VIEW



PARTS FOR TYPE 4251
20,000/24,000 WATT MOLEQUARTZ SOLARSPOT®

LAMP ASSEMBLY EXPLODED



LATCH PLATE 635-64 SCREW H594 WASHER H033 NUT H137
BAFFLE 630-71
LAMP HEAD ASSEMBLY 635-11
YOKE CLAMP PLATE 630-113 ATTACHES WITH SCREW H380 & WASHER H033
LENS CD06
FIBERGLASS TAPE FI07
LENS RETAINER RING 635-68
CLIP CP02 SCREW H342 WASHER H011 NUT H135
CLIP CP01 SCREW H360 WASHER H011
LENS GUARD 460-3
TOP CLIP 425-105
HINGE BLOCK 640-38
HINGE PIN 638-31
LATCH KNOB 470-37
LATCH SPRING 407-39
LATCH PIN 638-106
FLEX NUT H118
WASHER H092
CENTERING WASHER 555-139
SPRING 424-70
CENTERING WASHER 555-139
WASHER H092
SCREW H378 WASHER H013
FRICTION DISC 424-69
FRICTION DISC 425-58
PIVOT SPACER 424-72
SCREW H252 WASHER H033
(DOME. PART OF REAR DOOR FOCUSING ASSEMBLY)
WASHER H092
ARM 424-62
FRICTION DISC 425-58
SLIDE R.H. SLIDE L.H. (OPP SIDE) 424-64
YOKE TRUNNION PLATE 630-14 ATTACHES WITH SCREW H380 & WASHER H033
HINGE CLIP 638-103
LIGHT SHIELD 635-10
DIFFUSER SPACER 635-69 WITH SCREW H344 WASHER H011 NUT H135
DIFFUSER CLIP 635-67 WITH SCREW H327 WASHER H010 NUT H134
SWITCH CB22 SCREW H228
BAFFLE PLATES, BRACKETS, & HARDWARE PER 425-21
TROUGH REAR 425-47 ATTACHES WITH SCREW H347 WASHER H011
SWITCH COVER 418-23 ATTACHES WITH SCREW H360 & WASHER H011
SOCKET INSULATOR 415-61
SOCKET HOUSING 425-8
SOCKET CLAMP 415-140
SCREW 414-39
TROUGH WRAP 425-49
TROUGH FRONT 425-48 ATTACHES WITH SCREW H347 WASHER H011
WING NUT 414-27A
SKID 425-51 ATTACHES WITH SCREW H436 WASHER H011 NUT H135
STRAIN RELIEF BUSHING CN10
LOCK NUT LU96
CABLE 425-112
PIN PLUG MC259G
INSERT & LEAD, L.H. 425-10
INSERT & LEAD, R.H. 425-9
KNOB 500-731
BEARING BE09
TRUNNION (OPR.) 460-321
TRUNNION (OFF) 460-322
COMPLETE YOKE ASSY 635-154 (LESS 460-335)
SCREW H655
WASHER H042
SPACER 414-35
SCREW H1731 WASHER H072 WASHER H042
SPUD 460-335
ROLL PIN H1253 (4 PL)
YOKE ARM 460-320 (2 PL)
ROLL PIN H1256 (4 PL)
YOKE CASTING 460-319

Mole-Richardson Co.

PARTS FOR TYPE 4251
20,000/24,000 WATT MOLEQUARTZ SOLARSPOT®


REAR DOOR
FOCUSING ASSEMBLY
Rear View
LATCH SPRING 416-38
LATCH HANDLE 460-55 WITH
LATCH PIN 635-63
LATCH BRACKET SPACER 635-62
DOME 425-16
CAP NUT H921
SCREW H378
WASHER H033
FOCUSING CRANK 635-7
WITH PHENOLIC WASHER 103B-163
NUT H140
WASHER H034
SCREW H617
WASHER H034
HINGE
425-92
MIRROR RING
425-5
(MIRROR
416-10)
HINGE BACK-UP
PLATE 424-25
GLOBE SUPPORT
425-60
FOCUSING SCREW 424-26
WITH STOP COLLAR 450-69B & SET SCREW H1378
MIRROR RING 425-5
GUIDE ROD 424-27
GUIDE TUBE 425-12
CARRIAGE TIE ROD
416-30
SLIDE ROD TIE 424-17
SOCKET SUPPORT 425-59
END GUARD 460-165
HAND GRIP 460-164
SCREW H606
NUT H137
HAND GRIP POST 460-51
MIRROR RING 425-5
COTTER PIN H1317
WASHER H881
SPRING 416-36
MIRROR RETAINER
CLIP 416-33
MIRROR ADJUSTMENT
SCREW H534
NUT H140
LATCH BRACKET 460-142
SCREW H595
WASHER H013
NUT H137
SUPPORT PLATE 635-46
SCREW H613
WASHER H068
WASHER H034
NUT H137
WASHER H033
MIRROR
416-10
Front View
CAP NUT H921
SCREW H378
WASHER H033
TIE ROD 424-28
SOCKET SUPPORT
425-59
PIVOT SUPPORT 424-71
GLOBE SUPPORT
425-60
WING NUT
H716
NUT H137
WASHER H033
HINGE BACK-UP
PLATE 424-25
(DOME
425-16)
DOME BAFFLE
628-60
NUT H140
WASHER H034
SLIDE ROD TIE
424-17
CARRIAGE TIE ROD 416-30
GUIDE TUBE 425-12
TIE ROD 424-28
(SOCKET SUPPORT
425-59)

PARTS FOR TYPE 4821
TWEENIE SOLARSPOT®



PARTS FOR TYPE 4821
TWEENIE SOLARSPOT®


407-219
482-1p19
(h617)
482-1p18
(h034)
482-1p22
(be02)
482-1p17
(h068)
482-12p12
(h313)
482-12p13
(h009)
482-14
282-29
282-47
282-30
ri101
482-41
500-20c
482-12p12
(h313)
482-12p13
(h009)
482-78
482-1p23
(h486)
482-1p24
(h029)
482-40
406-63
cd05
ri101
482-12p13
(h009)
482-1p23
(h486)
482-1p24
(h029)
482-40
482-42
482-12p13
(h009)
407-182
482-38
482-12p12
(h313)
482-1p20
(sp08)
482-37
282-31
482-12p12
(h313)
482-1p21
(h1197)
482-36
482-9
482-1p24
(h029)
482-1p23
(h486)

PARTS FOR TYPE 4821
TWEENIE SOLARSPOT®


482–30p9
(h198)
404–18a
482–30p6
(h187)
482–30p10
(h009)
482–33
482–30p8
(h196)
482–30p10
(h009)
482–30p11
(sk16)
482–11p15
(buo6)
482–11p18
(nu16)
482–11p11
(h297)
482–31

PARTS FOR TYPE 4821
TWEENIE SOLARSPOT®


482–11p10
(h1126)
482–11p13
(h011)
282–36
282–57
482–11p19
(kn09)
482–11p13
(h011)
482–11p10
(h1126)
482–11p17
(h1399)
282–35
482–11p17
(h1399)
482–11p19
(kn09)
ri101
482–12p12
(h313)
482–11p16
(bu84)
400
482–11p9
(h324)
482–11p12
(h010)
482–11p14
(h134)
482–13

PARTS FOR TYPE 4821
TWEENIE SOLARSPOT®


∗ 400−91
500−1584
400−16
500−1585
500−1583

*Complete switch & cable assembly

PARTS FOR TYPE 5291
8" JUNIOR COOL REDHEAD®



529 (2000 WATTS)
8" JUNIOR COOL REDHEAD

Mole-Richardson Co.
Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail:info@mole.com Web:www.mole.com 937 N. Sycamore Ave., Hollywood,California 90038-2384 U.S.A.

PARTS FOR TYPE 5291
8" JUNIOR COOL REDHEAD®


LAMP HEAD ASSY.
528-10
TROUGH ASSY.
428-102
H359 (4PL)
H636
2000-38
H037
H070
410-52
BE09
625-94
428-63
H654
H042
H614
H014
YOKE ASSY.
414-68
406-63

PARTS FOR TYPE 5291
8" JUNIOR COOL REDHEAD®


528-48
H450 (4PL)
528-50
528-35 (SHEET METAL ASSY)
528-47 (END SPINNING) 2PL
528-49
H313 (2PL)
H744
H135 (3PL)
H031 (3PL)
413-85
CP02 (3PL)
H486 (3PL)
428-53 (3PL)
407-14 (3PL)
H344 (3PL)
H349 (3PL)
H362 (8PL)
H011 (8PL)
428-62
(ONTHE OTHER SIDE
528-24)
529-28
407-38
407-39
H313 (2PL)
407-37
428-75
413-84
H744
CD01
407-12A (2PL)
H197
H029

HEAD ASSY.

PARTS FOR TYPE 5291
8" JUNIOR COOL REDHEAD®



H800 (2PL)
H031 (2PL)
H880 (2PL)
220-32 (2PL)
406-26
407-98 (2PL)
H268 (2PL)
H499 (2PL)
428-70 (2PL)
H029 (2PL)
H197 (2PL)
632-90
428-89
632-89
400-69
H192
H011 (2PL)
H132
H065 (2PL)
428-104
H344 (2PL)
H011 (2PL)
428-21
428-26
428-24
TROUGH ASSY.
H105
428-43
H029 (2PL)
H133 (2PL)
410-11
H1399 (2PL)
H238 (2PL)
408-31
H031 (2PL)
400-1
H1126
H263 (2PL)
H031
H011 (2PL)
H031 (2PL)
H236
412-41
H029 (2PL)
H199 (2PL)
555-116 (2PL)
H199 (2PL)

PARTS FOR TYPE 5291
8" JUNIOR COOL REDHEAD®



CARRIAGE ASSY.
428 - 103



MIRROR ASSY.
428 - 88



CABLE ASSY.
400 - 69

PARTS FOR TYPE 5761
6 LIGHT MOLEQUARTZ MOLEPAR®



576 (6 LIGHTS)
MOLEQUARTZ MOLEPAR

PARTS FOR TYPE 5761
6 LIGHT MOLEQUARTZ MOLEPAR®


TOP HEAD ASSY.
H635
H037
H070
410–52
410–13
H582 (2PL)
2000–38
576–39
23–26
H617
BE09
H068
410–14
2000–47
2000–50
OR
2000–49
197–13 (2PL)
424–73

YOKE ASSY.
576 - 40

PARTS FOR TYPE 5761
6 LIGHT MOLEQUARTZ MOLEPAR®


FRONT VIEW
576-2 (3PL)
407-65 REF
H199 (12PL)
CP02 (12PL)
H009 (12PL)
H133 (12PL)
H011 (24PL)
H341 (24 PL)
227-19 (6PL)
H378 (4PL)
576-49 (6PL)
H137 (3PL)
H013 (3PL)
H067 (3PL)
KN06 (3PL)
577-38 (3PL)
H344 (4PL)
H011 (4PL)


TOP HEAD ASSY.
290-80 (2PL)
BE04 (2PL)
H591 (4PL)
H013 (4PL)
H596
BE04
407-65 (3PL)
576-29
576-55 (2PL)
576-61 (3PL)
RN19 (3PL)
400-16 (6PL)
576-98
HEX NUT SUPPLIED WITH SWITCH
H1460
SW14 (6PL)
558-22 (3PL)
400-115
CN09
H343
BACK VIEW
576-3
H342 (6PL)
H135
H011

Mole-Richardson Co.

PARTS FOR TYPE 5771
9 LIGHT MOLEQUARTZ MOLEPAR®



577 (9 LIGHTS)
MOLEQUARTZ MOLEPAR

PARTS FOR TYPE 5771
9 LIGHT MOLEQUARTZ MOLEPAR®


TOP HEAD ASSY.
H657
H042
H072
414-35
414-59
2000-38
577-39 (2PL)
H582 (2PL)
H658
410-73
BE04
577-59
H042
262-26
262-27
H614
H034
414-68 OR
414-93
424-73

YOKE ASSY.
577-6

PARTS FOR TYPE 5771
9 LIGHT MOLEQUARTZ MOLEPAR®


577-2 (3PL)
(HOUSING ASSY)
577-17 (3PL)
577-25 (3PL)
H199 (12PL)
CP02 (12PL) TOP 4
H009 (12PL)
H133 (12PL)
576-48 (3PL)
H342 (6PL)
CP03 (6PL)
H011 (6PL)
H135 (6PL)
576-49 (3PL)
H011 (48PL)
H341 (48PL)
H378 (4PL)
227-19 (9PL)
H137 (3PL)
H013 (3PL)
H067 (3PL)
KN06 (3PL)
FRONT VIEW
577-38 (3PL)
H344 (4PL)
H011 (4PL)
290-80 (2PL)
BE04 (2PL)
H591 (4PL)
H013 (4PL)
H596
BE04
407-65 (3PL)
577-78
TOP HEAD ASSY.
577-55 (2PL)
576-61 (3PL)
RN19 (3PL)
400-16 (9PL)
577-63 (3PL)
577-96
H135
H011
HEX NUT SUPPLIED W/ SWITCH
H1460 (9PL)
SW14 (9PL)
577-33 (3PL)
H343
CN10
400-127
H342 (6PL)
H011 (6PL)
576-3
BACK VIEW

2821A941

PARTS FOR TYPE 2821
600 WATT MOLEQUARTZ® TWEENIE-MOLE SOLARSPOT®


282-19
282-18P8
282-18P7
282-30
282-18P7
282-18P8
282-18P7
282-18P8
282-18P8
282-18P7
282-31
282-18P7
282-18P8
282-18P7
282-18P8
282-55
282-1P23
282-1P17
282-1P17
282-1P16
282-1P16
282-1P17
282-45
282-45
282-45
282-1P16
282-1P17
235-49
(4 15⁄32″ dia.)
282-47
282-1P13
282-1P14
282-1P15
282-1P18
407-219
282-29
406-63
500-20CP

(See Other Side)

Mole-Richardson Co.

2821B941

PARTS FOR TYPE 2821
600 WATT MOLEQUARTZ® TWEENIE-MOLE SOLARSPOT®


282-17P5
282-17P17
282-17P10
282-17P13
282-33 Mirror
282-53
282-48P9
282-48P9
282-48P12
282-48P12
282-17P14
282-17P12
282-17P9
282-57
282-35
282-36
282-28
282-17P13
282-17P17
282-17P10
282-17P5
282-48P7
282-48P7
282-48P10
282-48P10
282-17P15
282-17P11
282-48P8
282-48P8
282-48P11
282-48P11
282-49
282-17P16
282-48P5
282-34
282-34
282-48P11
282-48P11
282-48P8
282-48P8
400-65

4821A894

PARTS FOR TYPE 4821
650 WATT MOLEQUARTZ® TWEENIE II
SOLARSPOT®



482-14
482-12P13
482-12P12
282-30
482-12P12
482-12P13
482-12P12
482-12P13
482-12P13
482-12P12
282-31
482-12P12
482-12P13
482-12P12
482-12P13
482-1P23
482-1P24
407-182
235-49
407-182
482-1P24
482-1P23
482-40
482-41
482-12P13
482-12P12
482-1P23
482-1P24
482-36
482-40
482-9
482-1P24
482-1P23
482-36
407-182
482-1P24
482-1P23
482-1P23
482-1P24
482-36
482-38
482-1P20
482-1P12
482-1P13
482-42
482-37
482-1P21
482-1P22
407-219
482-1P19
482-1P18
482-1P17
282-47
282-29
406-63
500-20C

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

4821B894

PARTS FOR TYPE 4821
650 WATT MOLEQUARTZ® TWEENIE II SOLARSPOT®


482-11P17
482-11P19
482-11P10
482-11P13
282-35
282-36
482-11P14
482-11P12
482-11P16
282-57
482-11P14
482-13
482-11P13
482-11P10
482-11P19
482-11P17
400-91
482-30P6
404-18A
482-33
482-30P9
482-30P9
482-30P10
482-30P10
482-11P18
482-30P8
482-30P10
482-30P11
482-30P8
482-30P10
482-30P18
482-11P15
482-11P11
482-31

PARTS FOR TYPE 2831 1,000 WATT MOLEQUARTZ® BABY-BABY SOLARSPOT®


283-54
283-63
283-37
283-39
283-42
283-33
283-33
283-21
283-19
283-19
283-19
283-65
2351 ($4^{15}/_{32}''$ Dia.)
283-65
283-65
500-658
283-1P11
283-1P10
283-1P15
283-70
283-1P13 (Lock Washer)
283-1P12
283-69
40-88
283-20
406-63
280-13P
(SEE OTHER SIDE)

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet:http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

2831B941

PARTS FOR TYPE 2831
1,000 WATT MOLEQUARTZ® BABY-BABY SOLARSPOT®


283-29P22
283-30
400-35
418-55
500-26
413-33
283-22
400-15
418-55
418-55
551-26
551-26
500-28
551-26
551-26
283-101
500-27
283-35
283-35
283-109
283-35P4
283-107
283-106
283-72
413-95
283-43
283-60
407-73
283-66
407-65
407-66
407-70
407-68
283-59
283-36
283-108
407-64
283-58
283-103
283-29P21
MOLE-RICHARDSON

Mole-Richardson Co.

PARTS FOR TYPE 4131
2,000 WATT MOLEQUARTZ® BABY JUNIOR SOLARSPOT®


413-41
413-60
Set of 3 Screws 413-46P8*
Set of 3 Lug washers 413-46P9*
413-49
407-12A
413-84
407-12A
413-83
413-21
407-182
413-21
413-40P21
413-101
413-44P32
413-1P13
500-571
750-65
413-74
406-63
413-61
413-46P8* Set of 3 Screws
413-46P9* Set of 3 Lug Washers
413-63
413-45P5
413-85
407-38
407-182
407-39
407-37
413-40P19
(6″ Dia.)
413-21
407-182
413-75
413-51
413-1P12
413-1P11
413-1P10
206-24
413-42
500-20CP

*NOT SHOWN

NOT SHOWN: 413-196 LENS GUARD AND 308-26 KIT

(See Other Side)

PARTS FOR TYPE 4131
2,000 WATT MOLEQUARTZ® BABY JUNIOR SOLARSPOT®


418-55
418-55
220-19
413-33
419-65
418-55
220-14
220-15A
220-15A
413-62
220-14A
412-167
412-167
412-170
413-53
412-169
413-93
412-169
412-169
419-66
413-91
413-52
413-90
413-94
407-66
407-64
407-70
407-67
555-96
407-63
413-88
407-73
407-65
400-18
400-1
400-20
400-34
400-19

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet:http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 4281
2,000 WATT MOLEQUARTZ® 8″ JUNIOR SOLARSPOT®

Used Ser. Nos. 1 through 200


428-1P24
428-1P24
555-81
428-3 with Rivnuts
428-1P21
428-2P22
428-2P20
428-2P11
428-2P12
428-40
428-2P19
428-39
428-2P10
428-2P10
428-38
428-37
428-41
428-2P12
428-2P11
428-2P16
428-41
410-14
410-52
428-1P25
428-1P20
428-2P13
428-1P21
625-94
2000-38
428-1P19
428-4P5
410-13
428-1P16
428-1P22
410-20
428-4 Yoke Assembly
410-50
2000-49
428-53
428-1P14
(8″ Dia. Fresnel Condenser)
428-2P15
428-1P18
407-38
625-52
407-12A
407-14
625-31P5
625-31P6
407-14
413-85
428-2P18
428-2P18
413-84
428-2P15
407-39
407-12A
428-53
428-1P23
428-1P15
428-53
407-37
407-14

NOT SHOWN: 529-28 LENS GUARD AND 529-32 KIT

PARTS FOR TYPE 4281 2,000 WATT MOLEQUARTZ® 8″ JUNIOR SOLARSPOT®

Used Ser. Nos. 201 and Up.


428-77 with Rivnuts
428-62
428-79P11
428-79P12
428-59
428-79P18
410-52
428-1P20
428-1P21
428-1P19
428-79P16
625-94
2000-38
428-1P25
428-1P26
428-63
428-1P22
410-50
428-1P17
428-1P16
2000-49
428-53
428-75
428-1P14
(8″ Dia. Fresnel Condenser)
428-1P37
407-12A
428-79P17
428-74P5
407-38
413-84
428-74P8
407-14
407-14
428-74P7
428-74P6
428-79P14
413-85
428-79P17
428-79P14
407-12A
407-39
428-53
428-1P23
407-37
407-14
428-53

NOT SHOWN: 529-28 LENS GUARD AND 529-32 KIT

4281C941

PARTS FOR TYPE 4281 2,000 WATT MOLEQUARTZ® 8″ JUNIOR SOLARSPOT®

Used Ser. Nos. 1 through 150


428-6P18
428-6P15
428-6P14
428-13
428-7P9
428-10
428-43 (Rear)
428-6P15
428-7P7
428-7P8
428-13
428-7P6
428-10
428-8
428-24
428-26
428-6P14
428-6P16
408-31 (Front)
428-6P15
406-26
428-45P7
428-45P11
428-45P14
428-45P14
428-45P13
428-45P13
220-19
407-8P6
407-46
428-17
428-16P14
428-16P15
428-16P10
428-16P9
428-16P11
407-8P7
407-98
407-98
407-45
220-17A
220-14
413-130
220-32
220-32
428-16P16
428-16P15
428-20
220-16
407-8P8
400-68P9
428-21
220-17
400-68P10
400-68P8
400-18
428-45
Complete Socket
220-20
400-1
428-16P13
428-16P12
400-20
400-19
400-68

Mole-Richardson Co.

PARTS FOR TYPE 4281
2,000 WATT MOLEQUARTZ® 8″ JUNIOR SOLARSPOT®

Used Ser. Nos. 151 and Up.


428-71P17
428-71P18
428-43
428-71P16
428-71P21
428-71P25
428-71P24
428-71P26
428-71P32
428-71P28
428-71P25
412-41
400-1
410-11
428-68
555-117
428-71P32
428-71P28
428-71P20
428-24
428-26
428-71P18
428-71P16
408-31
428-71P17
406-26
428-54P12
428-54P9
428-54P11
428-54P11
428-54P13
428-54P13
220-19
428-16P7
428-16P8
407-46
428-17
407-98
428-16P11
428-16P9
407-8P6
407-8P7
407-98
220-17A
428-54P10
428-54P11
220-14 (Rear)
407-45
407-8P8
220-32
220-32
413-130
220-16 (Front)
428-16P12
428-16P8
428-82
428-21
428-54P15
428-54P15
428-54P16
428-54P16
428-81
428-70
428-70
428-54
Complete Socket
400-69

PARTS FOR TYPE 4191
5,000 WATT MOLEQUARTZ® BABY SENIOR SOLARSPOT®


410-128
419-4
419-55
419-8P3
410-129
410-52
419-1P11
419-1P12
419-1P10
500-570
2000-38
419-1P13
412-186
419-1P16
419-1P17
410-50
419-1P18
419-1P15
414-68
407-98
419-73
412-31
419-69
419-2P13
(9⁷/₈″ Dia.)
419-74
419-74
412-31
407-38
407-98
407-39
419-71
419-2P20
407-37
419-74
407-98

NOT SHOWN: 412-11 LENS GUARD AND 634-319 KIT

(See Other Side)

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet:http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

4191B941

PARTS FOR TYPE 4191
5,000 WATT MOLEQUARTZ® BABY SENIOR SOLARSPOT®


419-64
419-64
415-32
415-32
415-33
415-46
419-78
419-29
419-25
220-19
419-65
220-14
220-15A
220-14A
412-167
412-170
412-169
412-169
412-169
419-66
413-52
554-74
220-15A
412-167
419-36
418-55
419-15
414-91
414-91
226-24
226-24
414-92 (Pair)
414-92 (Pair)
419-10
419-3
419-25
419-44
419-44
419-11
413-53 Complete Socket Assembly
412-35
419-35
412-18
419-42
419-40
419-41
418-55
419-57 (Front)
555-94
412-29
412-46
419-38
412-47
412-21
419-53 (Rear)
418-55
419-16

PARTS FOR TYPE 4181
10,000 WATT MOLEQUARTZ® BABY TENER SOLARSPOT®


418-94P5
418-6
418-91
418-36
418-37
418-25
414-35
418-1P18
418-1P17
500-570
418-1P16
418-1P15
418-26
418-10
Complete
Yoke Assembly
418-50
(with tie-off loop)
414-73
418-50
424-73
461-3
418-1P16
418-1P17
418-7P12
418-20
461-102
418-1P20
415-34
418-7P12
418-1P19
418-96
414-68
418-100
418-97
418-7P12
415-83
418-7P13
(4611-H)
415-83
415-83
415-36
415-37
415-34
461-131
418-7P23
415-38
418-97

(SEE OTHER SIDE)

Mole-Richardson Co.

4181B963

PARTS FOR TYPE 4181
10,000 WATT MOLEQUARTZ® BABY TENER SOLARSPOT®


418-13 Complete Focusing Screw Assembly
418-15
418-14
418-77
418-78
418-9P9
418-23
418-78
418-77
418-73
418-235
418-18 Complete Socket Assembly
418-41
414-39
415-140
555-71
555-71
418-24
416-31
416-31
418-17
418-19
415-61
414-27A
418-16
418-42
418-54
418-32
418-55
418-34
418-4-P10
418-55
418-55
418-42
418-56
418-44
418-58
103B-163
418-43
461-44
461-44
418-33
418-45
418-39
418-40
418-40
418-90
418-53
418-53
418-5
418-31
418-59
226-24
414-91
414-91
226-24

2901A941

PARTS FOR TYPE 2901
200 WATT TINY-MOLE SOLARSPOT®


290-1P32
290-59
290-50
290-59
290-1P32
280-3
280-16
290-1P28
290-1P27
290-63
290-70
290-80P
290-1P23
290-72
280-13P
400-73
400-3P1
290-1P32
290-59
290-67
290-24 (Lens)
(2″ Dia.—1⁵/₈″ F.L.)
290-1P33
290-1P34
290-69
290-62
290-1P25
280-40
290-1P34
290-1P33
290-1P25
290-1P24
290-73
290-1P29
290-1P30
290-1P31
290-1P26
290-1P22
290-60
290-1P35
290-1P36
290-61

PARTS FOR TYPE 2801
200 WATT MINI-MOLE SOLARSPOT®

Used Ser. Nos. 1001 to 10,381


28012
2804
2803
28016
2801P18
2801P19
2801 LENS
(3″ Dia.-2½″ F.L.)
2805
(For 5⅛″ Accessories)
Standard 2806
(For 4 7/16″ Accessories)
2802
404-18A
2801P28
2801P30
28013P
2801P34
2801P29
2801P37
28013P
28010
2809
2801P24
2801P23
4005
2801P33
2808
28011
4003P1
2807
2801P25
2355

(See Other Side)

2801B941

PARTS FOR TYPE 2801
200 WATT MINI-MOLE SOLARSPOT®

Used Ser. Nos. 10,382 and Up


28012
2804
2803
28016
2801P18
2801P19
2801 LENS
(3" Dia. - 2½" F.L.)
2805
(For 5⅛" Accessories)
Standard 2806
(For 4⁷⁄₁₆" Accessories)
2801P28
2801P30
2802
404-18A
20813P
2801P34
2801P29
2801P32
2801P32
28010
40060
2809
280-40
28013P
2801P24
2355
2801P23
2801P33
28011
2807
4003P1
2801P25
2808

Mole-Richardson Co.

2351A941

PARTS FOR TYPE 2351
200 WATT MIDGET SOLARSPOT®
Used Ser. Nos. 973 Through 4498


235-10
404-18A
235-14
235-13
235-16
235-3P12
235-3P11
235-17
235-17
235-1P15
(4 15/32″ DIA.)
235-12
235-1P16
235-17
235-21
235-1P25
407-44P
235-1P23
235-1P24
235-11
400-3P1
235-1P10
235-19
500-20CP
235-1P17
235-18
235-5
235-15
400-4

(See Other Side)

2351B941

PARTS FOR TYPE 2351
200 WATT MIDGET SOLARSPOT®
Used Ser. Nos. 4499 And Up


235-10
404-18A
235-14
235-13
235-16
235-47
235-3P11
235-17
235-17
235-1P15
(4 15/32" DIA.)
235-12
235-1P16
235-17
235-21
235-1P25
407-44P
235-1P23
235-1P24
235-11
235-1P10
400-3P1
235-19
500-20CP
235-1P17
235-18
235-5
235-15
400-61

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 407
1,000 WATT BABY SOLARSPOT®
Used Ser. Nos. 301 to 3219


407-3P8
407-30
413-60
750-65
413-61
407-9P21
407-44P
206-24
407-9P18
407-9P19
407-9P20
406-66
406-63
500-20CP
40712A
407-12
TYPE 55 LENS
(DIA. 6″)
407-13
407-11
407-14
407-38
407-39
407-37
407-12A
407-14
407-14

NOT SHOWN: 413-196 LENS GUARD AND 308-26 KIT

(See Other Side)

PARTS FOR TYPE 407
1,000 WATT BABY SOLARSPOT®
Used Ser. Nos. 3220 and Up.


407-3P9
407-3P9
407-3P8
407-30
413-60
750-65
407-3P10
407-3P10
413-61
407-9P21
500-568P
206-24
407-9P18
407-9P19
407-9P20
406-66
406-63
500-20CP
407-182
407-9P15
407-9P24
407-12A
407-12
407-11P3
407-14
TYPE 55 LENS
(DIA. 6″)
407-11P3
407-12A
407-2P12
407-11
407-13
407-14
407-3P11
407-3P11
407-38
407-39
407-37
407-14
407-2P7
407-2P7
407-9P23

Note: For Lamps Ser. Nos. 1 through 3219, replace with 407-99

NOT SHOWN: 413-196 LENS GUARD AND 308-26 KIT

407C941

PARTS FOR TYPE 407
1,000 WATT BABY SOLARSPOT®
Used Ser. Nos. 301 through 16,988


407-236P30
407-75
407-236P29
407-72
407-236P23
407-22
407-60
407-236P21
407-236P27
407-62
407-236P28
407-236P20
400-16
407-236P19
407-236P22
407-64
407-67
407-236P18
406-26
407-236P19
407-9P17
407-74
408-58P14
407-58P8
407-58P12
407-236P23
407-63
407-69
407-58P14
407-32
407-73
407-65
407-8P6
407-8P6
407-8P7
407-8P7
407-98
407-98
407-66
407-70
407-45
407-68
407-236P30
407-57P5
407-57P6
407-8P8
407-71
407-46
407-61
407-58P11
407-58P10
407-58P9
750-15
407-10P25
407-42
400-10

NOTE: Serial Nos. 1 through 7231 used
407-41 2-wire cable

NOTE: 407-237 Socket Kit
available for replacement of
407-10P25, 407-42 and 750-15.

(See Other Side)

Mole-Richardson Co.
Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

407D941

PARTS FOR TYPE 407
1,000 WATT BABY SOLARSPOT®
Used Ser. Nos. 16,989 and Up.


407-236P30
407-75
407-236P29
407-72
407-236P23
407-22
407-60
407-236P21
407-236P27
407-62
407-236P28
407-236P20
400-16
407-236P19
407-236P22
407-64
407-67
406-26
407-236P18
407-236P19
407-9P17
407-74
408-58P14
407-58P8
407-236P23
407-58P12
407-63
407-69
407-58P14
407-32
407-73
407-65
407-8P6
407-8P6
407-8P7
407-8P7
407-98
407-98
407-66
407-70
407-45
555-96
407-236P30
407-57P5
407-8P8
407-57P6
407-71
407-46
407-58P11
407-61
407-58P10
407-58P9
407-235
407-230
407-228
407-227
COMPLETE SOCKET ASSEMBLY
551-26
551-26
283-35
407-232
283-106
283-35
551-26
551-26
400-70
407-229
407-231

NOTE: Serial Nos. 7232 through 26945 used 407-10 3-wire cable.

PARTS FOR TYPE 412
2,000 WATT JUNIOR SOLARSPOT®

Used Ser. Nos. 1 Through 11,999


482J3
412-10
410-128
410-129
410-52
410-14
410-13
603¼
410-73
412-40
Yoke less 2000-49
and 410-50
410-50
2000-49
412-11
412-12
412-31
412-19
412-20
412-20
412-31
407-35
412-13
407-38
407-39
412-20
407-37

(See Other Side)

PARTS FOR TYPE 412
2,000 WATT JUNIOR SOLARSPOT®

Used Ser. Nos. 12,000 And Up


412-2P8
412-10
410-128
410-129
412-1P15
410-73P
2000-38
412-1P18
412-1P20
412-1P19
410-52
410-50
412-186
412-1P28
412-1P29
412 1P38
412-1P37
414-68
412-1P16
412-31
407-98
412-11
412-13
412-20
412-1P17
410 Lens
9 7/8″ Dia.
412-20
412-12
412-31
407-98
407-38
407-39
407-37
412-20
407-98

NOT SHOWN: 412-11 LENS GUARD AND 634-319 KIT

PARTS FOR TYPE 412
2,000 WATT JUNIOR SOLARSPOT®

Used Ser. Nos. 1 Through 11,999


412-23
410-43
412-21
412-18
412-30
412-24
412-44
412-28
412-21
412-47
412-46
412-29
412-32
412-22
410-95
412-37
412-39
412-34
412-33
412-14
412-35
412-16
412-17
220-19
412-36
412-38
FLOOD
SPOT
220-14
410-11
100006
220-15A
412-41
220-14A
410-65
410-66
410-63
412-42

(See Other Side)

PARTS FOR TYPE 412
2,000 WATT JUNIOR SOLARSPOT®

Used Ser. Nos. 12,000 And Up


410-43
407-98
407-98
412-37
555-116
412-8P31
412-39
555-72
412-16
412-23
412-8P30
412-35
412-33
412-34
412-42
412-5P12
412-42
220-19
412-18
412-30
412-36
412-24
412-14
412-44
412-38
220-14
220-15A
220-15A
412-28
220-14A
412-8P30
412-167
412-21
412-167
412-170
4002
412-169
412-169
412-47
412-169
412-168
412-46
412-5P16
412-29
412-5P13
412-32
410-11
412-41
412-22AP4
4001
412-22

PARTS FOR TYPE 415
5,000 WATT SENIOR SOLARSPOT®


415-15
415-2P8
414-82
414-83
415-1P17
410-73P
414-35
415-1P20
414-58
415-1P19
415-1P18
424-73
414-59
414-30
415-1P18
415-1P19
414-73
40-88
415-1P16
415-1P15
414-57
415-1P22
414 Condenser
414-68
415-34
415-36
415-37
415-82
415-82
415-35
415-83
214-40
415-38
414-15
415-1P23
214-40
415-34
214-40

NOT SHOWN: 461-3 LENS GUARD AND 628A-335 KIT

(See Other Side)

415B941

PARTS FOR TYPE 415
5,000 WATT SENIOR SOLARSPOT®


414-45A
415-32
415-32
407-98
407-98
415-45
415-18
412-30
415-33
412-44
415-31
412-39
419-78
415-23
414-39
412-35
415-50
415-19
415-46
415-140
555-71
415-27
555-71
415-16
226-15
226-15
415-41
415-51
415-44
415-40
412-38
226-15
415-42
415-51
414-A (Set)
415-26
414-27A
415-25
415-61 (Pair)
415-29
415-24AP6
415-30
415-9P35
415-28
415-43
415-24
415-24AP5
415-5 Complete
Socket Assembly

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 416
10,000 WATT TENER SOLARSPOT®


416-80
416-47
416-48
416-51A
416-1P21
416-1P20
414-35
416-50A
416-91
414-66AP
40-88
42473
416-45
416-65
416-64
416-7P17
Included in 416-65
416-7P11
416-1P19
416-1P19
416-1P20
416-1P18
416-3P10 LENS
(DIA. 20 ")
416-1P26
416-1P25
414-57
416-55A
416-58
416-39
416-38
416-49
416-37
416-22
416-44
416-22
414-68
416-22

NOT SHOWN: 416-104 LENS GUARD AND 416-341 KIT

(See Other Side)

PARTS FOR TYPE 416
10,000 WATT TENER SOLARSPOT®

416B941


416-5P7
416-5P8
416-5P10
416-5P9
416-36
416-33
416-33
416-36
416-33
416-36
416-46
416-5P8
416-5P7
416-5P10
416-5P9
416-10
416-5P6
416-123
416-123
416-124
416-122
416-122
416-125
416-120P5
416-127
416-126
416-126
414-64
416-5P9
416-5P10
416-5P7
416-5P8
416-43
416-75
416-42
416-63
414-42
414-41
416-8P5
416-31
416-31
414-39
416-30
415-140
555-71
555-71
226-15
416-15
226-15
226-15
414-27A
415-61
416-12
415-61
416-60
416-60
416-62
414-18B
414-51
414-43
414-29A
414-64
414-43
414-51

Mole-Richardson Co.

4241A941

PARTS FOR TYPE 4241
10,000 WATT "BIG EYE" TENER
SOLARSPOT®


416-47
416-48
42433
1205-J
1205-J
42431
42437
42433
42436
42451
42445
42445
4248
42410
42446
42451
42437
42437
42464 (L.H.)
42464 (R.H.)
42480
4241 LENS
(24¾" DIA.)
4244 P7
4245
410-73
414-35
603¼
416-50A
416-51A
42438
40-88
42473
42438
414-57
42447
414-68
1105
1105
42452
42475
1205-J
1105
1105
42443
42452
42452
1205-J

(See Other Side)

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 4241
10,000 WATT "BIG EYE" TENER
SOLARSPOT®


42420
42471
42472
42462
42461 P7
42461 P6
42461 P8
42470
42461 P8
42461 P6
42469
42469
42416
416-36
416-33
416-33
416-36
42459
416-36
416-33
42426
42449
450-69B
42427
42427
TE 122Y-100
42460
42444
42444
42429
42429
42430
226-24
226-22
226-22
226-24
416-94
416-31
416-31
4241 P47
4241 P46
42458
42456
42457
42453
42471
42472
42462
42461 P7
42461 P6
42461 P8
42470
42461 P8
42461 P6
42469
42469
103B-163
90-99C
90-99B
42414
42425
416-10
42428
42428
42417
42450
42450
415-61
416-12(SET)
415-61
414-27A
414-39
414-27
42448
416-30
226-15
226-15
226-15
416-15

PARTS FOR TYPE 4031 600 WATT MOLEQUARTZ® TEENIE-WEENIE MOLE


403-15P11
403-15P12
403-63
403-15P11
403-15P12
403-15P11
403-15P12
403-15P10
403-45
403-15P12
403-15P11
403-15P11
403-15P12
403-38
403-38
403-38
403-48
403-29
403-29
403-29
403-21
403-15P12
403-15P12
403-15P11
403-15P12
403-15P11
403-15P11
500-658
403-1P11
403-1P10
403-1P9
403-1P8
403-47
403-17
28013P

PARTS FOR TYPE 4031
600 WATT MOLEQUARTZ® TEENIE-WEENIE MOLE

4031B941


408-31
403-19P19
403-46
403-27
403-14P6
403-14P7
403-14P6
403-14P7
403-19P15
403-19P16
403-19P16
403-19P15
403-19P12
403-14P7
403-14P6
403-14P6
403-14P7
403-32
403-19P13
403-19P13
403-41
403-19P16
403-19P15
403-31
403-64
403-41P2
403-36
403-36
403-34
403-19P14
403-19P11
403-35
400-45
403-19P16
403-19P16
403-19P15
403-19P15

Mole-Richardson Co.

PARTS FOR TYPE 4051
650 WATT MOLEQUARTZ® TEENIE-MOLE


405-1 P28
408-31
408-14 P2
408-14 P2
405-20
408-15
408-15
28013P
405-1 P20
405-1 P24
405-1 P17
405-1 P23
408-26
405-32
406-63
28013P
400-24
408-20
408-32
405-1 P18
405-31
405-25 P6
400-6
405-26

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

4081A941

PARTS FOR TYPE 4081
1,000 WATT MOLEQUARTZ®
MICKEY-MOLE


408-31
408-IP24
408-10
408-14P2
408-14P2
408-15
408-15
28013
408-IP16
408-1P13
408-IP21
408-IP19
408-26
408-25
406-63
28013
408-20
408-32
408-23
408-16P7
4008
408-1 P15
500-26
408-1 P15
400-15
408-1P14
500-28
500-27
408-62

PARTS FOR TYPE 4091
2,000 WATT MOLEQUARTZ®
MIGHTY-MOLE


409-1 P27
408-31
409-20
409-26 P3
409-26 P3
409-27
409-27
500-16P
409-1 P16
409-1 P19
409-1 P24
409-1 P22
206-24
409-38
406-63
500-20CP
409-71
409-29
409-37
409-36
409-28 P7
409-1 P18
400-18
409-1 P18
409-1 P17
400-1
400-20
400-17
400-19
409-31

PARTS FOR TYPE 3311
1,000 WATT MOLEQUARTZ® 1K MOLETTE
BARE BULB FIXTURE


331-3
331-15
331-1P3
331-1P9
331-1P9
331-16
331-1P12
331-10
331-1P8
280-13P
500-26
400-15
500-28
500-27
400-29

PARTS FOR TYPE 3321
2,000 WATT MOLEQUARTZ® 2K MOLETTE
BARE BULB FIXTURE


332-3
400-18
332-19
400-1
332-1P13
818-77
400-20
332-18
400-19
332-1P16
332-1P16
332-1P16
400-13
332-10
332-30
280-13P
332-1P17

PARTS FOR TYPE 2911 650 WATT MOLEQUARTZ® ONE-LIGHT NOOKLITE


2912
29111
2911P18
2000-32
29111
2911P18
2000-32
29121
28013
2914
2913
2913
291-1P10
291-1P10
4006
2355
5410
291-1P17

PARTS FOR TYPE 2921 1,000 WATT MOLEQUARTZ® 1K NOOKLITE


292-9
292-1 P28
292-16
292-16
292-1 P23
292-22
292-1 P24
28013P
292-1 P25
292-1 P34
292-1 P14
408-26
292-23
406-63
28013P
292-14
292-44
292-44
292-1 P15
292-1 P15
292-1 P33
292-1 P17
292-1 P29
500-26
292-1 P16
400-15
500-28
400-32
500-27

PARTS FOR TYPE 2941
2,000 WATT MOLEQUARTZ® 2K
NOOKLITE


294-41
294-1 P19
294-20
294-20
750-65
294-1 P17
294-1 P22
500-16P
294-1 P21
294-1 P20
294-40
206-24
406-63
500-20CP
294-12
294-39
294-39
294-1 P16
294-1 P16
294-1 P34
294-1 P32
400-18
294-1 P18
400-1
400-20
400-13
400-19

2931A941

PARTS FOR TYPE 2931
1,950 WATT MOLEQUARTZ® THREE-LIGHT NOOKLITE


2931P20
29314
29314
29313
2931P17
2931P17
2931P17
2934
2933P4
2931P11
2933P5
2914
2933P5
29315
2935
29315
2933P4
2931P11
2933P5
2914
2933P5
29315
2935
29315
2933P4
2931P11
2933P5
2914
2933P5
2913
2931P22
29111
2000-32
2932
28013
29321
2000-32
29111
2931P222

Mole-Richardson Co.
Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

2981A941

PARTS FOR TYPE 2981
650 WATT MOLEQUARTZ® MINI-SOFTLITE


298-15
292-22
298-1P14
280-13P
298-39
298-1P17
298-1P16
298-1P15
298-1P13
298-23
298-21P4
298-21P3
298-21
(DOES NOT INCLUDE 554-37)
40-88
298-1P18
298-1P19
406-63
554-37
500-20CP
406-63P4
298-14
298-13
298-2P16
298-13
298-1P12
298-3
298-2P11
298-8
298-2P16
298-2P8
298-2P12
298-2P13
298-2P9
298-2P8
298-8
298-2P10
298-2P10
400-72P4
400-72P3
400-72
400-24

Mole-Richardson Co.

PARTS FOR TYPE 2581
750 WATT MOLEQUARTZ® BABY SOFTLITE


500-16
2581-P11
750-65
25816
206-24
2581-P16
406-63
406-66
500-20C
25815
25814
25814
2583
2588
2588
2582-P8
2582-P8
2582-P9
400-24
4009

PARTS FOR TYPE 2591
2,000 WATT MOLEQUARTZ® 2K BABY "ZIP®" SOFTLITE


259-18
557-42
259-1P13
500-571
259-1P12
206-24
259-1P14
259-1P15
259-1P16
259-20
406-63
500-20CP
259-27
25814
25814
259-26
259-26
259-33
2568
2568
259-62
259-62
259-61
259-61
259-19P17
259-19P17
259-28
259-39
259-39
259-39
259-39
259-19P16
259-19P16
400-16
400-16
259-19P15
259-51
259-38
400-39

PARTS FOR TYPE 3571 4,000 WATT MOLEQUARTZ® 4K BABY SOFTLITE


357-11
2000-38
245-13
357-1P14
23-14
357-1P17
500-570
357-1P15
357-1P16
410-14
410-20
226-24
414-91
414-91
410-50
357-1P9
357-1P10
226-24
2000-49
55474
357-32
258-14
25814
259-26
259-26
259-27
357-37
357-37
2568
2568
357-36
357-36
357-10P26
357-10P26
357-10P17
357-10P17
259-39
259-33
400-16
400-16
357-31
259-39
357-26
357-27
259-39
226-24
226-24
400-16
400-16
357-12
400-41
400-41
357-35
259-39
357-10P26
357-10P26
500-512
500-512

Mole-Richardson Co.

PARTS FOR TYPE 2551 1,000 WATT MOLEQUARTZ® SUPER-SOFTLITE


410-73
2551-P13
2000-38
410-14
410-20
410-50
2553-P7
2553
2552-P8
400-15
255-34
3213-P4
32114
255-33
25510
23-14
245-13
25518
2000-49
40010
2552-P10
3213-P4
255-33
255-34

2561A941

PARTS FOR TYPE 2561 2,000 WATT MOLEQUARTZ® SUPER-SOFTLITE


25613
410-73P
2561 P13
2000-38
410-14
410-20
410-50
2561 P14
2561 P15
2561 P16
23-14
245-13
25618
2000-49
257-70
256-20
400-15
2562 P8
2562 P9
256-64
2562 P9
2562 P8
400-15
256-20
2567
2562 P12
25621
2566 P6
2568
2566 P6
25610
25533
2561-P18
2561-P17
2563-P7
2563
4007
2562 P11
2566 P6
2568
2566 P6
2567
25533

2571A941

PARTS FOR TYPE 2571
4,000 WATT MOLEQUARTZ® SUPER-SOFTLITE


25711
410-73
2571-P12
414-58
42473
25719
2571-P16
2571-P17
2572-P17
2572-P17
2573-P8
2572-P11
400-15
2572-P11
400-15
2572-P11
400-15
2572-P11
400-15
2572-P12
2575
2568
2566-P6
2566-P6
255-33
2567
2571-P13
2571-P14
2571-P15
246-15
22338
226-24
414-91
414-91
226-24
414-90
2000-49
226-24
226-23
2574
2574
226-23
226-24
2573
2567
2568
2566-P6
2566-P6
25610
255-33

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 2621 8,000 WATT MOLEQUARTZ® SUPER-SOFTLITE


262-17
262-31
262-29
262-28P5
262-28P4
262-28P4
262-28P6
262-32
262-18
262-18
410-73P
262-1P21
262-1P24
262-1P29
262-1P28
414-35
42473
42473
414-90- Two required per fixture.
226-24
414-91
414-91
226-24
262-24
262-1P23
262-1P29
262-1P32
262-1P31
414-68

PARTS FOR TYPE 2621 8,000 WATT MOLEQUARTZ® SUPER-SOFTLITE


262-2P8
262-2P8
262-2
262-7P10
255-33
255-33
2567
2568
2568
262-14P6
262-14P6
262-14P6
262-14P6
262-15
2567
2575
262-7P10
262-8
262-7P10
262-37
262-16
400-15
400-15
400-15
400-15
262-11P9
262-11P9
262-11P8
262-11P8
262-11P8
262-11P8
262-12
262-12
262-34P2
262-34P2
262-7P11
262-34P6
262-34P6
262-34P7
262-34P7
262-34P8
262-34P8
262-34P9
262-34P9
262-34P3
262-34P3
262-34P4
262-34P4
262-34P5
262-34P5

8142A953

PARTS FOR TYPE 8142 1,000 WATT MOLEQUARTZ® 14″ FIXED FOCUS SCOOP


551-59
814-85P3
818-86
814-10
814-5
Optional
with fixture.
814-13
814-90P3
814-13
814-85
Standard
with fixture.
818-89
818-73
818-78
500-26
400-15
500-28
500-27
818-91
818-7
818-67
818-67
818-67
814-19P21
814-2P32
814-19P19
814-19P20
814-19P20
814-19P14
2000-38
400-31
Optional
with fixture.
814-19P23
814-19P17
814-19P15
818-60
410-73P
814-19P22
818-92
Used with
400-31 only.
818-51

PARTS FOR TYPE 8182
2,000 WATT MOLEQUARTZ® 18″ FIXED FOCUS SCOOP


551-59
400-18
400-1
400-20
400-19
400-42 Optional with fixture.
818-5 Optional with fixture.
818-91
818-67
818-97P12
818-67
818-2P45 Use with 400-42 only
818-67
818-97P23
2000-38
410-73P
818-97P20
818-92 Used with 400-42 only.
818-10
818-78
818-7
818-2P32
818-97P22
818-97P23
818-97P21
818-97P15
818-97P18
818-97P16
818-60
818-51
818-85P3
818-86
818-13
818-13
818-85 Standard with fixture.
818-90P4
818-77
818-89
818-73

Mole-Richardson Co.

PARTS FOR TYPE 8141 1,000 WATT MOLEQUARTZ® 14″ FOCUSING SCOOP


551-59
814-85P3
818-86
814-10
814-85
Standard with fixture.
818-9
814-5
Optional with fixture.
818-78
818-31
818-8P16
818-8P16
818-31
814-13
814-18P24
814-13
818-11
818-32
818-8P14
818-12
818-25
412-32
818-64P4
818-28
818-64P4
818-30
818-91
500-26
400-15
818-6
500-27
818-7
500-28
818-67
818-67
818-67
814-1P32
814-18P26
814-18P27
814-18P27
814-18P25
2000-38
400-31
Optional with fixture.
814-18P16
814-18P20
814-18P18
818-60
410-73P
814-18P23
818-51
818-92
Used with 400-31 only.

Mole-Richardson Co.

PARTS FOR TYPE 8181 2,000 WATT MOLEQUARTZ® 18″ FOCUSING SCOOP


551-59
818-5 Optional with fixture.
818-91
818-67
818-6
818-67
818-1P45 Used with 400-42 only.
818-96P28
2000-38
410-73P
818-96P24
818-92 Used with 400-42 only.
400-18
400-1
400-20
400-19
818-67
400-42 Optional with fixture.
818-10
818-13
818-96P25
818-13
818-11
818-7
818-9
818-78
818-1P32
818-96P27
818-31
818-96P28
818-8P16
818-96P26
818-96P17
818-96P21
818-96P19
818-60
818-51
818-85P3
818-86
818-85 Standard with fixture.
818-77
818-8P14
818-25
818-64P4
818-28
818-64P4
818-30
412-32
818-12
818-32
818-31
818-8P16

PARTS FOR TYPE 3211
1,000 WATT MOLEQUARTZ® BROAD


321-3P17
321-3P17
321-12
321-13
321-3P17
321-13
321-3P17
321-3P8
321-3P8
321-3P7
321-3P7
321-3P6
321-3P6
321-3P4 (W/ 14" LONG LEAD)
321-3P4 (W/ 3" LONG LEAD)
32114
321-3P17
321-3P5
321-3P7
321-3P6
321-3P17
321-3P5
321-3P7
321-3P6
321-1P16
321-12
321-1P15
321-2P17
500-25P5
500-25P6
500-25P5
500-25P6
500-26
400-15
400-8
500-28
500-27

PARTS FOR TYPE 3211
1,000 WATT MOLEQUARTZ® BROAD


321-2P7
321-2P7
321-2P8
321-2P6
321-2P8
321-2P9
321-2P9
321-2
321-1P30
321-1P30
357-91
321-1P29
321-93
321-1P30
321-92
321-1P30
321-89
750-65
321-1P11
407-44
321-1P13
321-1P14
321-1P12
206-24
3218
500-20C
406-63

Mole-Richardson Co.

3221A948

PARTS FOR TYPE 3221 2,000 WATT MOLEQUARTZ® DOUBLE BROAD


322-2P9
322-2P9
322-2P6
3222
321-1P30
321-1P30
322-1P22
322-9
322-1P22
321-1P30
321-93
321-1P30
321-92
322-62
750-65
322-1P13
500-16
322-1P23
322-1P24
322-1P25
206-24
3227
406-63
500-20C

PARTS FOR TYPE 3221 2,000 WATT MOLEQUARTZ® DOUBLE BROAD


322-10
322-1P21
322-1P29
400-15
322-1P16
322-1P15
322-1P29
322-19
322-1P21
322-1P18
322-1P21
322-1P29
400-15
322-1P16
322-1P15
322-1P29
322-19
322-1P21
322-1P19
322-20
322-1P22
321-12
322-1P22
321-12
321-3P4 w/ 10" Lead
321-3P6
321-3P7
321-3P5
321-3P4 w/ 17" Lead
321-3P6
321-3P7
321-3P5
321-3P4 w/ 17" Lead
321-3P6
321-3P7
321-3P5
321-14
321-3P6
321-3P7
321-3P8
322-1P22
321-14
321-3P6
321-3P7
321-3P8
322-1P22
321-13
322-1P22
321-13
321-12
321-13
322-1P22
321-13
321-12
322-1P22
322-1P22
4007

Mole-Richardson Co.

3401A951

PARTS FOR TYPE 3401 2,000 WATT MOLEQUARTZ® SUPER-BROAD


3232
3232-P9
3232-P9
3232-P5
3232-P11
3232-P10
3232-P10
3232-P11
323-19
750-65
340-1P13
500-16P
340-1P14
340-1P15
340-1P16
206-24
406-63
321-8
500-20CP
321-12
340-1P20
340-1P20
340-3P8
340-3P9
340-3P10
340-3P17
340-3P17
340-3P8
340-3P9
340-3P10
340-3P17
340-3P17
321-14
340-3P6
340-3P8
340-3P9
340-1P23
340-3P6
340-3P8
340-3P9
323-12
321-13
340-3P9
340-3P8
340-3P9
340-3P8
321-13
321-12
340-1P21
400-28P9
400-28P8
400-28P8
400-28P9
400-28P10
400-28
400-28P10
400-18
400-28P14
400-28P10
400-28P13
400-28P14
400-28P10
400-28P13
400-1
400-20
400-19

Mole-Richardson Co.

PARTS FOR TYPE 5711
650 WATT MOLEQUARTZ® ONE-LIGHT MOLEFAY®


551-29
551-27
554-16
551-21
551-21
571-20
551-25
551-25
554-101
554-28
554-23
571-14
554-54
554-25
COMPLETE SOCKET ASSEMBLY
571-1P20
571-19
400-24
571-1P16
552-32
571-1P18
571-1P19
572-30
571-1P18
571-1P17
571-16
28013
552-54
400-27

PARTS FOR TYPE 5721
1,300 WATT MOLEQUARTZ® TWO-LIGHT MOLEFAY®


28013
554-77
572-1P20
554-25
COMPLETE SOCKET ASSEMBLY
407-65
554-23
572-20
554-54
551-28
554-101
554-16
572-24P6
572-10P7
551-27
554-27
572-26
551-29
551-25
551-25
572-23
551-21
551-21
400-16
572-32
572-7P2
572-22
572-1P20
572-1P15
572-1P16
572-30
407-65
572-46
572-1P14
572-21
572-31P7
572-7
28013
552-54

PARTS FOR TYPE 5581
2,600 WATT MOLEQUARTZ® FOUR-LIGHT MOLEFAY®


28013
554-25
COMPLETE SOCKET ASSEMBLY
558-1 P15
554-76
407-65
554-77
554-54
551-28
554-101
558-18
551-27
554-16
554-23
558-26
551-29
551-25
551-21
558-6 P7
558-5 P6
554-27
551-21
551-25
558-11
558-30
554-88
400-16
554-83
558-16
558-21
558-1 P13
554-65
558-1 P19
558-1 P18
558-1 P17
407-65
554-26
558-8 P7
558-7 P2
558-7
558-20 P5
558-20 P6
554-85
500-20C
554-37

PARTS FOR TYPE 5591
3,900 WATT MOLEQUARTZ® SIX-LIGHT MOLEFAY®


28013
559-1 P15
554-25
COMPLETE SOCKET ASSEMBLY
407-65
554-54
559-13
551-28
554-101
551-27
554-16
554-23
558-26
551-25
551-21
551-29
558-6 P7
551-25
551-21
554-77
559-17 P6
554-27
554-76
554-28
554-88
554-83
559-18
559-21
400-16
559-19
414-91
559-16
559-1 P24
557-41
557-42
226-24
554-26
554-66
COMPLETE PIN-PLUG ASSEMBLY
559-35
554-69
554-70
554-68
414-92
(Pair)
554-74
557-44
414-68

PARTS FOR TYPE 5541 5,800 WATT MOLEQUARTZ® NINE-LIGHT MOLEFAY®


28013
554-1 P25
407-65
554-23
554-18
554-16
554-41
554-6 P8
554-77
554-76
554-75
554-27
554-5 P6
554-25
COMPLETE SOCKET ASSEMBLY
554-54
551-28
554-101
551-27
551-29
551-25
551-21
551-25
551-21
554-28
554-78
554-79
554-88
554-83
400-16
554-40
554-1 P24
414-91
226-24
557-41
557-42
554-26
414-92
(Pair)
554-100
554-69
554-70
554-68
554-74
554-66
COMPLETE PIN-PLUG ASSEMBLY
557-44
414-68

PARTS FOR TYPE 5571
7,800 WATT MOLEQUARTZ® TWELVE-LIGHT MOLEFAY®


28013
557-1 P22
554-25
COMPLETE SOCKET ASSEMBLY
554-16
407-65
554-54
554-23
551-28
554-18
554-101
551-27
551-29
551-25
551-25
551-21
551-21
557-18
554-77
554-6 P8
554-76
557-5 P6
554-75
554-27
557-11
554-88
557-27
554-83
554-78
400-16
554-79
557-16
414-91
557-1 P21
557-41
226-24
554-26
557-42
414-92
(Pair)
554-68
554-70
554-69
554-74
554-66
COMPLETE PIN-PLUG ASSEMBLY
557-44
557-45
414-68

Mole-Richardson Co.

PARTS FOR TYPE 2271
1,000 WATT MOLEQUARTZ® MOLEPAR®


227-1P21
227-26
500-26
227-1P23
400-15
500-28
400-8
500-27
227-20
227-19
227-58
227-56
227-1P28
227-18
227-28
227-28
750-65
227-1P20
227-28
500-16P
227-1P13
227-1P18
227-1P16
206-24
406-63
227-27
500-20CP

PARTS FOR TYPE 4711
600 WATT MOLEQUARTZ® ONE-LIGHT
MOLECOOL®


471-10P3
471-24
471-10
5600ºK Reflector and stippled Lens Assembly
471-21P5
471-10P2
471-21P4
471-20
471-21
Lens and Reflector Housing Assembly
471-20P5
471-20P4
471-16
471-1P29
471-1P24
471-1P29
471-1P28
471-1P27
471-1P29
471-34
471-1P32
471-33
589-54
471-1P29
471-34
471-1P30
589-16
589-54
471-1P27
471-1P28
471-33
471-1P31
471-35
400-24
471-1P33
552-32
471-1P22
471-1P22
471-1P23
572-30
471-1P21
571-16
280-13
400-64
406-63

5891A941

PARTS FOR TYPE 5891
5,400 WATT MOLEQUARTZ® NINE-LIGHT MOLECOOL®


28013p
589-1P22
589-1P23
589-1P23
589-11
5600°K Reflector Assembly
589-23
589-29
589-10P13
589-10P11
589-53
589-10P12
407-65
589-20
589-10P19
589-54
589-10P10
589-10P11
589-77
589-74
589-10P18
589-10P10
589-10P11
589-13
589-10P15
589-10P17
589-10P16
589-10P14
589-15
589-10P15
589-19
589-18
589-16
589-10P11
589-10P10
589-11P4
Reflector
554-27
589-47P6
589-48
589-75
589-63
Stippled Lens Assembly
589-63P5
Lens
589-65
589-64
589-69
589-68
589-67
589-59
589-50
589-70
589-39
589-49P7
589-49P6
589-66
400-16
554-83
414-91
226-24
414-92
(Pair)
589-1P24
557-41
554-26
557-42
554-69
554-70
554-68
554-100
5891-P19
5891-P18
5891-P17
554-74
Cable Assembly
554-66 Complete
Pin Plug Assembly
557-44
589-1P26
589-1P28
414-68

Mole-Richardson Co.

PARTS FOR TYPE 245
5,000 WATT SKYLITE


245-11
245-11
245-10
245-1P11
410-73P
245-12
245-1P18
245-1P17
245-1P16
410-14
245-13
245-9
414-39
245-18
245-1P23
415-140
226-15
245-1P22
555-71
555-71
226-15
415-61
226-15
414-A (SET)
414-90
2000-49
415-61
240-16
414-27A
240-17
240-19
240-19
414-60
M R
419-78
29-62
226-24
226-24
500-518
245-16P4
414-91
500-518
245-16P4
226-24
414-91
245-16
226-24

PARTS FOR TYPE 16
1,000 WATT CINELITE


16-14
16-20P20
16-1
16-6
16-20P18
21-27
16-4
16-20P17
16-20P16
16-2
16-20P16
16-20P17
16-3
200-41BP
16-20P21
16-20P15
500-20CP
16-13
400-12
500-26
500-25P7
400-16
ON
OFF
500-27
500-25P6
500-25P5
500-28

PARTS FOR TYPE 1000 1,500 WATT BELL LAMP


1000-6
1000-1AP16
21-27
200-41BP
1000-5
1000-1AP17
1000-20
1000-10
1000-10
21-20
4001
1000-7
16-13
500-20CP
4002

8011A9311

PARTS FOR TYPE 8011
1,000 WATT MOLEQUARTZ® MOLELIPSO®


801-46
802-70
801-71
801-52P18
801-52P19
407-39
801-52P17
802-65
802-69P4
801-62
801-56P3
801-61
801-20
Reflector
801-89P5
801-89P6
801-85
801-85
801-89P9
801-52P13
801-52P13
801-89P6
801-89P5
Socket Insulation
(Supplied with Socket)
500-26
801-87
400-15
500-28
801-89P7
801-89P8
801-54
500-27
801-89P7
801-89P8
801-89P7
801-89P8
801-52P12
400-8
Optional with Fixture
801-109
801-52P12
801-52P14
801-52P21
801-52P14
801-52P21
801-86
(Set 3 leads)
801-57
801-19P32
801-19P30
801-19P31
801-19P31

PARTS FOR TYPE 8011
1,000 WATT MOLEQUARTZ® MOLELIPSO®


801-31
801-19P22
801-19P20
801-19P21
801-19P21
801-19P19
801-19P20
802-36
802-38
802-39
802-37
802-35
801-19P21
801-19P20
801-19P19
801-19P22
801-19P20
801-19P21
801-19P21
801-19P19
801-19P20
802-36
802-38
802-39
802-37
802-35
801-19P21
801-19P20
801-19P19
801-24P7
801-33
801-24P5
555-87
801-24P6
801-24
Complete
Aperture Assembly
801-21
Aperture Plate
801-26

8011C9311

PARTS FOR TYPE 8011
1,000 WATT MOLEQUARTZ® MOLELIPSO®


801-106
801-51
801-73
801-82
801-77P8
801-77P7
801-81
801-77P6
500-570
801-1P12
410-14
801-1P9
801-1P10
801-1P11
410-52
410-13
802-80
Used with
400-8 only
801-1P7
801-1P8
801-83

Mole-Richardson Co.

PARTS FOR TYPE 8014 AND 8016 ACCESSORY LENS ASSEMBLIES

8011D9311


TYPE 8014
TYPE 8016
801-94
801-93
801-17
4½″×9″ Lens
802-16
6″×12″ Lens
801-4P17
801-4P16
801-104
801-4P12
801-6P17
801-6P16
801-6P12
802-104
801-104
802-104
801-17
4½″×9″ Lens
801-104
802-16
6″×12″ Lens
802-119
801-4P15
802-119
801-6P15
802-95
801-4P14
801-4P13
802-95
802-95
802-95
802-95
801-6P14
801-6P13
802-95
802-95
801-224
801-224
802-67
802-67

PARTS FOR TYPE 8012 AND 80112 ACCESSORY IRIS ASSEMBLIES


TYPE 8012
TYPE 80112
801-2P9
801-2P9
801-163
801-2P9
801-2P9
801-12P7
801-12P7
801-163
801-12P7
801-12P7
801-2P11
801-2P13
801-2P12
801-39
With Pins
801-12P8
801-12P10
801-12P9
801-153
With Pins
801-151
12 Per Unit
801-151
18 Per Unit
18920
18920
18920
18920
18920
18920
18920
18920
801-42
801-155
802-44
802-44
802-44
802-44
802-44
802-44
802-44
802-44
801-2P10
801-161
801-2P10
801-2P10
801-2P10
801-162
555-106
802-159
801-160P8
801-160P8
801-159
801-160P8
801-160P8

PARTS FOR TYPE 8021
2,000 WATT MOLEQUARTZ® MOLELIPSO®


802-46
802-20
Reflector
802-70
802-62
802-56P3
802-71
802-61
407-39
802-65
802-69P4
220-19
225-22
802-53
Complete Socket
Assembly.
220-14
220-15A
220-15A
220-14A
412-167
412-167
412-170
412-169
412-169
412-169
412-168
400-18
400-1
400-20
400-19
802-89P6
802-89P7
802-54
802-52P12
Used with
400-36 only.
802-89P6
802-89P7
802-89P6
802-89P7
802-109
400-36
Optional
with fixture.
802-57
802-64
802-52P24
802-150
802-19P32
802-19P30
802-303
(Set 3 leads)
802-19P31
802-19P31

Mole-Richardson Co.

PARTS FOR TYPE 8021
2,000 WATT MOLEQUARTZ® MOLELIPSO®

8021B941


802-31
802-19P22
802-19P20
802-19P21
802-19P21
802-19P19
802-19P20
802-36
802-38
802-39
802-37
802-35
802-19P21
802-19P20
802-19P19
802-19P22
802-19P20
802-19P21
802-19P21
802-19P19
802-19P20
802-36
802-38
802-39
802-37
802-35
802-19P21
802-19P20
802-19P19
802-24P7
802-33
802-24P5
555-87
802-24P6
802-24
Complete
Aperture Assembly.
802-21
Aperture Plate.
802-26

PARTS FOR TYPE 8021
2,000 WATT MOLEQUARTZ® MOLELIPSO®


802-106
802-51
802-73
802-82
802-81
500-570
802-1P11
802-115
802-1P12
802-1P13
802-1P14
414-35
802-116
802-83
802-80
Used with
400-36 only.
802-117

PARTS FOR TYPE 8026 AND 8028 ACCESSORY LENS ASSEMBLIES

8021D941


TYPE 8026
802-16
6″ x 12″ Lens
802-104
802-104
802-16
6″ x 12″ Lens
802-104
802-6P17
802-6P16
802-6P12
802-94
802-119
802-6P15
802-95
802-95
802-6P14
802-6P13
802-95
802-168
802-67
TYPE 8028
802-93
802-18
8″ x 21″ Lens
802-103
802-8P12
802-8P16
802-8P17
802-103
802-18
8″ x 21″ Lens
802-119
802-8P15
802-95
802-8P14
802-8P13
802-95
802-95
802-168
802-67

PARTS FOR TYPE 8022 AND 80212 ACCESSORY IRIS ASSEMBLIES


TYPE 8022
TYPE 80212
802-12P13
802-2P9
802-2P9
802-12P13
802-163
802-163
802-2P9
802-2P9
802-12P13
802-12P13
802-2P11
802-2P13
802-2P12
802-12P15
802-12P17
802-12P16
802-40
802-153
802-151
12 Per Unit
802-151
18 Per Unit
18920
18920
18920
18920
18920
18920
18920
18920
18919
802-155
802-44
802-44
802-44
802-44
802-44
802-44
802-44
802-44
802-2P10
802-2P10
802-43
802-2P10
802-2P10
802-156
555-89
802-159
802-160P8
802-160P8
802-161
802-160P8
802-160P8

PARTS FOR TYPE 1963 FOGMAKER MOLEFFECT®


19657
19656
19656
19653
19657
19658
19658
19651
19654
19655
19655
19662
19661
19650
19649
19648
19646(115V.)
19647(230V.)
19663
19642(115V.)
19643(230V.)
19640(115V.)
19641(230V.)
19659
19644(115V.)
19645(230V.)
19652

(SEE OTHER SIDE FOR PARTS DESCRIPTION)

PARTS FOR TYPE 1963 FOGMAKER MOLEFFECT®

PART NO.	NAME	DESCRIPTION
19640	Boiler Assembly (115 V.)	Boiler (115 V.), Top Flare Fitting, Adjusting Pin with Bar & Lock Nut. (To install, lower boiler tube must be threaded through plate and flared).
19641	Boiler Assembly (230 V.)	Same as Part No. 19640 except boiler is rated at 230 Volts. (To install, lower boiler tube must be threaded through plate and flared).
19642	Boiler & Plate Assembly (115 V.)	Boiler (115 V.), Plate, Retaining Ring, Float Guide Tubes, Flare Fittings, Adjusting Pin with Bar & lock Nut.
19643	Boiler & Plate Assembly (230 V.)	Same as Part No. 19642 except boiler is rated at 230 volts.
19644	Boiler, Switch, & Plate Assembly (115 V.)	Boiler (115 V.), Switch (115 V.), Plate, Retaining Ring, Float Guide Tubes, Flare Fittings, Adjusting Pin with Bar & Lock Nut. (Switch Pre-adjusted at Factory).
19645	Boiler, Switch, & Plate Assembly (230 V.)	Same as Part No. 19644 except boiler & switch are rated at 230 volts. (Switch pre-adjusted at factory).
19646	Switch (115 V.)	Thermostatically Controlled Switch, Complete (115 V.)
19647	Switch (230 V.)	Thermostatically Controlled Switch, Complete (230 V.)
19648	Adjusting Pin	
19649	Adjusting Pin Bar	
19650	Adjusting Pin Lock Nut	
19651	Plate Assembly	Plastic Plate & Float Guide Tubes.
19652	Bottom Case	
19653	Plate Gasket	
19654	Retaining Ring	
19655	Float Guide Tube	
19656	Filler Cap	
19657	Filler Cap Gasket	
19658	Filler Cap Ring	
19659	Flare Fitting	
19660	Cord Assembly (2-wire)	Cord, House Plug, & Female Connector.
19661	Female Connector (3-wire)	
19662	Recessed Connector (3-wire)	Recessed Connector, Wires, & Terminals.
19663	Cord Assembly (3-wire)	Cord, U-Ground House Plug & Female Connector.

PARTS FOR TYPE 1963 FOGMAKER MOLEFFECT®


19682
19687
19683
19685
19686
19684
19688
19689
19665
19675
19674
19673
19672
19671
19681
19677
19676
19676
19690
19668
19669
19670
19667
19666
19679
19678
19680
OR FOG JUICE
NO FOG JUICE

(SEE OTHER SIDE FOR PARTS DESCRIPTION)

PARTS FOR TYPE 1963 FOGMAKER MOLEFFECT®

PART NO.	NAME	DESCRIPTION
19665	Cover Assembly	Cover, Handle, Pilot Light Assembly, Recessed Connector Assembly, Wire Holder, Wires & Terminals.
19666	Pump Assembly	Pump Barrel Assembly, Knob, Side Check Valve, Lower Check Valve, & Gasket.
19667	Pump Barrel Assembly	Pump Barrel with Piston.
19668	Tube & Screen Assembly	
19669	Tube	
19670	Tube Screen	
19671	Nozzle & Strainer Assembly	Nozzle Assembly, Strainer Body, Screen.
19672	Nozzle Assembly	
19673	Nozzle Screen	
19674	Strainer Body	
19675	Strainer Gasket	
19676	Float Assembly	Float Rod, Cork & Nut.
19677	Float Nut	
19678	Lower Check Valve	
19679	Check Valve Gasket	
19680	Side Check Valve	
19681	Pump Knob	
19682	Handle	
19683	Pilot Light Assembly	Socket, Shield, & Globe.
19684	Pilot Light Socket	
19685	Pilot Light Shield	
19686	Pilot Light Globe	
19687	Wire Holder	
19688	Cover	
19689	Wire Set	All Wires & Terminals.
19690	Hardware Set	All Screws, Nuts, & Washers.

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

TYPE 1963
FOGMAKER MOLEFFECT®

ADJUSTMENT INSTRUCTIONS
FOR
THERMOSTATICALLY CONTROLLED SWITCH

GENERAL—The temperature of the flash boiler within the Fogmaker is maintained at its proper value by a thermostatically controlled switch. When the temperature is too low the switch is closed, and the pilot light is ON indicating that the heating element in the flash boiler is energized. When the temperature rises to the proper value the switch opens, and the pilot light goes OFF indicating that the flash boiler is up to temperature and that its heating element is de-energized. Proper adjustment of the switch is essential. If the flash boiler temperature is maintained at too low a value, complete vaporization of the Fog Juice will not take place. If the temperature is permitted to become too high, the Fogmaker will be damaged.

The following instructions describe re-adjustment of the switch, or initial adjustment with newly installed parts:

1—Start with the Fogmaker at room temperature. A unit which has been sitting overnight with its cord unplugged will be at room temperature.

2—Remove cover.

3—Loosen lock nut on adjusting pin at center of adjusting pin bar above switch.

4—*For previously adjusted switch*—Back out adjusting pin about 1 turn from its previously adjusted position, or *For newly installed parts*—Position adjusting pin so that there is about 1/16 inch air gap between its lower end and the switch contact arm.

5—Plug cord into a voltage supply whose voltage value is the same as is stated on the Fogmaker nameplate, either A.C. or D.C., and note the exact time that the cord was plugged in. The pilot light will come ON when the cord is plugged in.

6—When the Fogmaker has been plugged in for exactly 7 minutes and 45 seconds, *immediately* advance the adjusting pin to the point where the switch snaps open and the pilot light goes OFF.

7—Un-plug Fogmaker cord.

8—Tighten lock nut *SECURELY* without disturbing position of adjusting pin.

9—Replace cover.

NOTE: The Fogmaker should be periodically checked for proper switch adjustment, by measuring the time required for the pilot light to go OFF after the machine is plugged into proper voltage from a *COLD* start. If the time is less than 7 minutes 15 seconds, or more than 8 minutes 15 seconds, the switch should be re-adjusted per above instructions.

PARTS FOR TYPE 1971 WINDMACHINE MOLEFFECT®

Serial Number 1 - 1681


19733-2
No. 2 Wire
19733-1
No. 1 Wire
19732
1971P24
1971P22
1971P24
1971P24
1971P24
1971P46
1971P46
1971P32
1971P32
1971P32
1971P32
1971P33
1971P33
1971P34
1971P34
19753
19754P3
19756
19729P6
19728
19729P7
19729P8
19726
19729P8
19729P7
400-16
1971P28
1971P26
410-73P
410-14
410-20
410-50
1971P30
19714
19757
19758
19759
19760
1971P31
1971P33
1971P32
410-13
410-52
1971P32
19711
1971P41
1971P36
40010
2000-49

(SEE OTHER SIDE)

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 1971 WINDMACHINE MOLEFFECT®

Serial Number 1 - 1681



PARTS FOR TYPE 1971
18″ WINDMACHINE MOLEFFECT®
Serial Number 1682 and Up


197-33†
Wire #2
197-32†
197-33†
Wire #1
197-1P45
197-28
197-1P44
197-1P42
197-1P43
197-29P6
197-29P8
197-29P7
197-26
197-1P43
197-1P42
197-1P44
*197-1P46
*197-1P47
*197-1P43
*197-1P42
197-1P49
197-1P9
400-16
197-1P13
197-1P3
197-1P35
197-1P37
197-1P36
197-1P4
197-1P37
197-1P35
19757†
Wire #3
19758†
Wire #4
197-1P50
19759†
Wire #5
19760†
Wire #6
19786
197-54P7
197-54P5
197-56
197-54P3
197-53
197-54P6
197-54P8
197-54P13
197-1P38
197-1P39††
197-1P40
197-1P41
500-570
197-1P22
424-73
400-10
197-84
197-1P25
197-1P24
197-1P25
197-1P26
414-35
197-82
197-1P30
197-1P26
197-1P31
197-1P37
414-93
414-68
500-182
According to Application

*Same Part Nos. as Above

†See 197-55 (Wiring Diagram)
†† As Needed for Snug Fit

Mole-Richardson Co.
Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 1971
18″ WINDMACHINE MOLEFFECT®
Serial Number 1682 and Up


197-1P47
*197-1P42
*197-1P48
197-92
197-27
197-9
197-1P47*
197-1P42*
197-1P48*
197-90
197-1P43**
197-1P42**
197-1P48**
197-1P52**
*197-1P47
*197-1P42
*197-1P48
197-8
197-75
197-1P54
197-1P53
197-73

*Set of Six Required, **Set of Four Required

PARTS FOR TYPE 5601 MOLEPAC STAND (½″Tube)


560-31
560-31
560-31
560-31
560-14
5/8″ Tube
Assembly
560-15
3/4″ Tube
Assembly
560-16
7/8″ Tube
Assembly
560-17
1″ Tube
Assembly
560-24
560-25
560-26
560-34
560-31
560-1P5
560-12P9
560-13
1/2″ Tube
Assembly
560-12P11
560-33
560-36
560-35
(2 required)
560-12P9
560-37
(3 required)
560-32
560-12P8
560-12P10

PARTS FOR TYPE 5602
MOLEPAC STAND (3/8″ Tube)


560-53
560-53
560-43
1/2″ Tube
Assembly
560-47
560-53
560-44
5/8″ Tube
Assembly
560-53
560-45
3/4″ Tube
Assembly
560-46
560-2P10
560-41
560-53
560-42P8
560-54
(Three required)
560-40
560-42P9
560-55
(Three required)
560-42P7
560-42P8

PARTS FOR TYPE 5603 MOLEPAC STAND (5/8″Spud)


560-31
560-31
560-31
560-56
560-58P3
560-58P3
560-58
Spud and Tube
Assembly
560-57
560-15
3/4″ Tube
Assembly
560-16
7/8″ Tube
Assembly
560-17
1″ Tube
Assembly
560-24
560-25
560-26
560-34
560-31
560-3P5
560-12P9
560-12P11
560-36
560-35
(Two required)
560-33
560-37
(Three required)
560-12P10
560-32
560-12P9
560-12P8

1391A8111

PARTS FOR TYPE 1391 BABY SIZE LOW STAND


500-20CP
129-13
1395
129-12
1392
1394
1393
1391P19
1391P17
1393P4
410-109
1391P18
1393P4
406-52
1391P18
406-56
406-54A
406-53
1391P9
1391P16
406-65

PARTS FOR TYPE 40651A (STANDARD) BABY SIZE PEDESTAL


129-43
500-20CP
129-31
129-12
129-13
500-20CP
406-58
406-59
406-60A
406-51AP23
410-109
555-56
406-52
406-54A
406-53
406-51AP21
406-56
406-51AP22
406-57
406-65
406-51AP22
406-51AP19

PARTS FOR TYPE 1581
BABY SIZE SKY-HI STAND


158-2
129-13
200-41BP
129-31
129-43
500-20C
200-41BP
200-9C
410-133
200-41BP
410-134
410-132
406-60A
406-59
410-139
410-136
410-135
1581P28
410-109
1581P26
1581P27
555-56
410-105B
410-131
406-56
1581P27
1581P29
410-104
1581P14
406-65

PARTS FOR TYPE 1561
JUNIOR SIZE SKY-HI STAND


200-41BP
211-20A
200-41BP
26-22
26-21A
200-41BP
200-9C
410-133
200-41BP
410-134
410-132
1561P26
410-140
410-139
410-136
410-135
1561P22
1561P23
1561P24
410-109
410-131
406-56
410-105B
1561P10
410-104
406-65
1561P25
1561P23

1851A777

PARTS FOR TYPE 1851
BABY SIZE SKY-HI LITEWATE STAND


500-20C
129-43
500-20C
1819
1859
1818
1853P4
1852P4
1852P5
1853P5
1854
1853P3
1856
1855
2548
555-56
18515P13
1858
18510
500-20C
32812
1851P6
18110
1851P8
1851P9
1851P8
1851P8
1851P7
1851P5

2541A777

PARTS FOR TYPE 2541
BABY SIZE COMPACT LITEWATE STAND


500-20C
129-43
1819
500-20C
1859
1818
2543P4
2543P5
2543P3
2544
2542P4
2542P5
2545
2546
2548
25410P13
555-56
1858
18510
500-20C
2541P6
2541P8
2541P8
18110
32812
2541P8
2541P7
2541P5
2541P9

3281A8310

PARTS FOR TYPE 3281
BABY SIZE LITEWATE STAND


32814
3283P4
3283P5
500-20C
129-13
32813
32816
3284P4
3284P4
32815
3284
Complete Elevating Tube Assembly
32817
32819P10
500-20C
32810
26-22
3281P7
3281P9
3281P9
32811
32812
3281P5
3281P9
3281P8
3281P6

Mole-Richardson Co.
Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 410138
JUNIOR SIZE PEDESTAL (STANDARD)


200-41BP
200-10A
200-41BP
200-9C
410-133
410-132
200-41BP
410-134
410-136
410-135
410-137
410-109
410-105B
410-138P21
406-56
410-138P19
410-104
410-138P20
410-138P20
406-65
410-131
410-138P22
410-138P8

Mole-Richardson Co.

500557859

PARTS FOR TYPE 500557 JUNIOR SIZE LITEWATE LOCATION STAND


500-558P15
500-558P20
500-559
500-557P15
500-557P13
345-16
345-5P4
345-5P4
500-568
500-483
500-568
200-9C
500-558P17
500-558P16
500-479
500-481
500-558P18
500-558P18
500-558P15
500-568
500-558P17
418-238
345–4
Complete Slotted Leg Assembly.
500-557P11
500-557P13
500-557P13
500-478
500-480
500-482
345–5
Complete Leg Assembly.
Two per stand.
500-20CP
500-557P14
500-558P19
500-560
500-555
500-568
500-557P15
500-557P13
500-557P13
500-556
500-557P13
500-557P11
500-557P16
500-557P14
500-557P14
345-7
500-557P14
500-557P12
345-19
345-8

PARTS FOR TYPE 500791 JUNIOR SIZE SKY-HI LITEWATE LOCATION STAND


500-800P26
500-800P22
500-800P25
500-800P26
500-580
500-795
500-791P17
500-791P17
500-481
500-791P17
500-791P16
500-791P13
500-568
500-568
345-16
500-800P23
500-800P26
500-800P20
345-5P4
500-479
200-9C
500-800P20
500-568
500-631
500-796
345-5P4
418-238
500-568
500-482
345-4
500-480
500-815
500-791P11
500-20C
500-800P21
500-797
500-798
500-800P26
500-800P25
500-791P15
500-791P11
500-579
500-791P15
500-791P11
500-791P11
500-791P11
500-799
170-50
345-8
500-568
500-791P11
500-791P11
500-791P14
500-791P12
345-19
345-5

345-4 Complete Slotted Leg Assembly.

345-5 Complete Leg Assembly. Two per stand.

PARTS FOR TYPE 1411
JUNIOR SIZE LOW STAND


200-41BP
200-10A
200-41BP
1413
220-12
200-9C
1412
1411P21
410-109
1411P19
1411P20
410-105B
410-103
1411P20
406-56
1411P22
1411P12
410-104
406-65

PARTS FOR TYPE 41475 (SINGLE LIFT) SENIOR SIZE STAND


200-41BP
200-10A
200-9C
220-12
414-76
200-41BP
414-75P19
414-75P23
414-75P25
414-75P21
414-77
414-80
414-81
406-65
414-75P24
410-109
414-75P16
410-104
410-103
414-75P22
414-75P23
414-75P22
406-56
414-75P23
414-75P23
414-78A
414-75P20
414-75P21

PARTS FOR TYPE 41494 (DOUBLE LIFT) SENIOR SIZE STAND (STANDARD)


200-41BP
410-134
414-76A
200-10A
200-41BP
200-9C
200-41BP
410-133
410-132
414-94P28
414-94P27
414-94P22
414-94P25
410-136
410-137
414-97
414-77A
414-94P26
410-109
406-56
414-94P24
414-94P25
414-78B
414-94P25
500568
414-94P23
414-94P8
406-65
410-104
410-131

Mole-Richardson Co.
Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 500476
JUNIOR SIZE LITEWATE STANDARD STAND

500476A859


500-568
410-134
500-479
500-476P23
500-476P25
500-478
500-568
200-9C
500-481
500-476P24
500-476P25
500-480
500-476P26
500-476P26
500-568
500-483
500-482
500-477
316-29
406-65
500-476P21
500-476P22
500-476P22
500-476P20
500-476P27
410-109
410-105B
406-56
500-476 P7

PARTS FOR TYPE 1571
SENIOR SIZE SKY-HI STAND


200-41BP
200-41BP
26-21A
200-41BP
410-133
26-22
200-41BP
200-9C
211-20A
1571P30
410-132
410-134
1571P25
414-76A
1571P28
410-136
410-139
1571P31
1571P32
414-77A
414-97
410-140
1571P27
1571P29
410-109
414-78B
1571P28
410-131
406-56
1571P28
500-568
1571P26
410-104
1571P10
406-65

PARTS FOR TYPE 418181
SENIOR SIZE LITEWATE LOW STAND


500-568P
200-10A
418-181P11
418-181P11
418-203
500-568P
418-181P10
418-207P18
200-9C
410-133
500-568P
418-238
418-206
418-181P9
418-181P11
418-216
418-208
Complete Leg
Assembly.
418-209
418-208P4
418-208P4
345-16
418-208P4
418-212
418-208P4
418-210
418-211
500-577
418-187
Complete Leg
Brace Assembly.
418-207P17
418-181P8
418-200
418-201
418-181P13
418-181P7
418-181P12
418-195
500-578
418-187P3
418-187P3
500-578
418-181P8
418-204
200-41BP
418-181P15
418-205
418-181P7

Mole-Richardson Co.

418182A8510

PARTS FOR TYPE 418182
SENIOR SIZE LITEWATE STANDARD STAND


418-182P11
418-182-P10
418-182P11
418-203
418-196P18
418-182P11
418-182P9
418–186
Complete Leg
Assembly.
345-16
418-186P6
418-186P6
418-194
418-186P6
418-186P6
500-577
418–187
Complete Leg
Brace Assembly.
418-182P8
418-182P7
418-195
418-182P12
418-187P3
500-578
418-187P3
500-578
418-182P15
418-182P13
500-568P
418-206
418-238
418-216
418-197
418-196P17
418-200
418-201
500-568P
410-133
200-9C
418-198
500-568P
200-10A
418-199
418-182P8
418-204
200-41BP
418-205
418-182P7

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 418183
SENIOR SIZE LITEWATE SKY-HI STAND


500-568P
500-568P
410-133
200-10A
200-9C
418-184P21
418-183P11
418-183P10
418-183P11
418-219
500-568P
500-631
316-16
500-568P
410-132
418-238
418-183P11
418-183P9
418-186
Complete Leg
Assembly.
418-185
418-217
345-16
418-194
-418-188
-418-189
418-186P6
418-186P6
500-577
418-186P6
418-186P6
418-183P8
418-187
Complete Leg
Brace Assembly.
418-184P20
418-191
418-192
418-190
418-183P7
418-183P12
500-578
418-195
500-578
418-183P8
418-187P3
500-579
200-41BP
418-187P3
170-50
418-183P13
418-183P15
418-183P7

5611A813

PARTS FOR TYPE 5611
SENIOR SIZE LONG LEG STAND


200-41BP
200-41BP
414-76A
410-133
200-10A
200-41BP
1¼ in. dia.
410-132
5611P22
5611P25
410-134
200-9C
410-137
410-136
414-97
5611P28
5611P27
414-77A
5611P26
5611P24
5615
5611P25
5612
410-131
23″
5614
5611P25
5611P23
410-104
5611P8
406-65
500-568

3441A833

PARTS FOR TYPE 3441 LOW ALUMINUM MOLEFLECTOR® STAND



344-1P18
344-1P14
344-18
500-568
344-10
344-2P9
344-2P9
344-1P14
345-16
344-4P4
344-4P4
344-1P14
344-18
344-1P12
344-2P11
344-2P11
344-3
Complete Slotted Leg Assembly.
344-4
Complete Leg Assembly. Two per stand.
344-7
344-2P10
344-1P15
500-20C
344-11
344-12
344-1P18
344-1P14
344-6
500-568
344-1P19
344-1P15
200-9C
345-6
344-1P14
344-1P15
344-5
344-1P14
344-1P15
344-1P12
344-1P13

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

3163A859

PARTS FOR TYPE 3163
MEDIUM ROLLER FOLDING STAND


500-568P
418-238
500-568P
200-9C
500-568P
200-10A
500-568P
500-631
410-132
410-133
316-16
316-37
316-13
316-14
316-15
316-12P15
316-12P14
316-12P13
316-36
316-12P7
316-12P8
316-18P5
316-18P5
316-39
316-38
316-18P5
316-17
316-18P5
316-29
316-12P6
406-65
316-18

Mole-Richardson Co.

PARTS FOR TYPE 500572
FOLDING CRANK-UP LITEWATE STAND


500-572P11
500-572P14
500-580
500-572P14
500-572P14
500-572P10
500-600
Complete Leg
Assembly
345-16
500-600P6
500-600P6
500-601
500-617
Complete Column
Assembley-See over
for Details.
500-587
Complete Leg
Brace Assembly
500-572P9
500-572P7
500-572P12
500-572P13
500-600P6
500-600P6
500-577
500-588
500-572P12
500-572P6
500-587P3
500-578
500-587P3
500-572P13
500-578

PARTS FOR TYPE 500572
FOLDING CRANK-UP LITEWATE STAND


500-568
500-610
500-580
500-605P14
500-605P14
500-617P16
500-617P15
500-613
500-617P15
500-617P16
500-617P16
500-617P15
500-617P16
500-617P15
500-603P13
500-605P10
500-617P21
500-617P20
500-568
500-581
500-582
500-603P11
500-598
500-616
500-596
500-599
500-617P15
500-617P16
500-583
500-607
500-597
500-602
500-603P11
500-603P13
500-612
500-611
500-573
500-603P17
500-603P16
500-603P15
500-603P12
500-591P11
500-594
500-595
500-591
500-593
500-617P23
500-634
Crank and Handle Assembly
500-579
200-41B
170-50
500-605P11
500-606
500-592
170-51
500-614
500-608
500-609
170-52
500-615
500-617P17
500-604
500-605P12
500-605P13

TYPE 325
MOLEVATOR®


Figure 3
Figures 1 & 2
Figure 4
Figure 1

TYPE 325
MOLEVATOR®

PARTS ORDERING INFORMATION

IMPORTANT

Please furnish serial number of Molevator® for which parts are required.

Note 1: If motor (325-92) is needed for replacement in a Molevator® serial number 1 thru 202, the following parts are required:
325-138 Motor Replacement Kit consisting of the following:
325-92 Motor
325-110 Motor Mounting Frame Assembly
325-117 Motor Sprocket Assembly (and mounting hardware:
325-91 P28, 325-91 P29, 325-91 P31)
325-121 Relay Mounting Assembly
325-122 Motor Cover Assembly

Note 2: If complete motor mounting assembly (325-91) is purchased for replacement in a Molevator® serial numbered 1 thru 202, the following part is also required:
325-122 Motor Cover Assembly

MAINTENANCE INSTRUCTIONS FOR TYPE 325 MOLEVATOR®

MANUAL OPERATION

In case of power or other failure:
1 - Disconnect Power Supply.
2 - Remove Bottom Pan (325-29)
3 - Hold Sprocket (325-141) from turning
4 - Remove chain connector link and chain (325-2 P13)
5 - Rotate Sprocket (325-141) to raise or lower

LUBRICATION (every six months)

COLUMN ASSEMBLY:
1 - Remove Top Casting (325-50)
2 - Pour in 2 to 3 fluid ounces of Mineral Oil without additives S.A.E. 250 viscosity, 600 minium flash (M-R 600W Gear Oil).
3 - Replace Top Casting (325-50)
4 - Operate to distribute oil.

RISER TUBES:
Wipe powdered graphite on exposed surface.

AT BOTTOM PAN:
Lower Bearing - Apply Valvolene BG-3 Wheel Bearing Grease or equivalent with gun at fitting (325-7 P2).
Drive Chain - Apply Mineral Oil, medium consistency without additives, on chain plates (325-2 P13). Wipe off excess oil.

WIRING DIAGRAM INSIDE MOTOR COVER (325-122)

PARTS FOR TYPE 325 MOLEVATOR®

When Ordering, Designate Serial Number of Molevator®


A
(Figure 2)
B
(Figure 2)
C
(Figure 2)
450-213

Figure 1

PARTS FOR TYPE 325 MOLEVATOR®

When Ordering, Designate Serial Number of Molevator®


325-1 P20
325-1 P22
325-54
325-72 P5
325-67
325-57 P6
325-58
325-60
325-59
325-1 P15
325-1 P15
325-51
325-68 P5
325-68 P5
325-1 P22
325-1 P21
325-1 P14
325-72 P5
325-65
325-53
C
325-1 P20
325-1 P22
325-1 P23
325-55
325-54
325-74 P7
325-73 P5
325-73 P5
325-148
325-69 P6
325-69 P6
325-1 P14
B
200-41BP
325-71
410-73P
325-1 P23
325-52
325-1 P17
325-1 P18
325-1 P19
325-61
325-74 P6
90-133A
410-73P
325-1 P23
325-52
325-67
325-74 P7
325-147
325-70 P7
325-70 P7
325-1 P14
A

Figure 2

PARTS FOR TYPE 325 MOLEVATOR®

When Ordering, Designate Serial Number of Molevator®


325-31
325-33
325-48A
325-3 P16
325-3 P13
325-3 P14
200-41BP
325-50
325-3 P15
325-6 P6
325-14
325-5 P8
325-13
325-3 P13
325-3 P14
325-32
325-34
325-47A
325-3 P17
325-95
325-38
450-245
325-42
325-46
325-151
325-11
325-5 P10
325-12
325-20
325-5 P9
325-146*
325-15
325-3 P18
325-4 P8
325-4 P7
325-4 P6
325-17
325-19
325-7 P4
325-7 P2*
325-7 P6
325-7 P5
325-85
325-2 P10
325-2 P11
450-245
325-141
325-5 P11

***NOTE: Important—furnish serial number of Molevator when ordering this part.**

Figure 3

PARTS FOR TYPE 325 MOLEVATOR®

When Ordering, Designate Serial Number of Molevator®


325-10 P3
325-10 P2
325-10 P1
325-10
325-91 P20
325-121 P11
325-121 P9
325-87
325-91 P17
325-91 P18
325-121 P8
325-91 P19
325-10
325-129*
325-121 P13
325-121 P12
325-121 P14
325-112*
325-131*
325-28 P2*
325-28 P2*
325-28 P2*
325-28 P2*
325-121*
325-102
325-77
325-78
325-110*
325-92*
325-28 P2*
325-28 P2*
325-79
325-79A P4
325-122*
325-118*
325-102
325-77
325-78
325-2 P13
325-117*
325-91 P31
325-91 P29
325-91 P28
325-91*
325-150
325-29

***NOTE: Important—furnish serial number of Molevator when ordering this part.**

Figure 4

TYPE 103B MICROPHONE BOOM
WITH
OPERATING and MAINTENANCE INSTRUCTIONS

TYPE 126B PERAMBULATOR
INSTRUCTIONS

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

TYPE 103B MICROPHONE BOOM OFF SIDE

Figure Numbers Refer to Pictures on Following Pages and Letters to Re-Stringing Information


SEE FIG 13
L
K
INSIDE SEE FIG 12
SEE FIG 11
J
H
SEE FIG 10
G
F
E
SEE FIG 9
SPUD 126B-36 (NOT SHOWN)
SEE FIG 8
D
SEE FIG 7
SEE FIG 6
C
SEE FIG 5
R
SEE FIG 4
B
SEE FIG 3
A

FIGURE 1

TYPE 103B MICROPHONE BOOM OPERATING SIDE

Part Numbers Refer to Next Page and Letters to Re-Stringing Information


P
O
103B-155
103B-124
103B-155
QUADRANT LOCK SCREW
N
M
CLAMP KNOB
ROTATION LOCK KNOB
L
K
J
COUNTERWEIGHT BOX ATTACHES HERE (SEE FIG. 11)
H
G
F
E
103B-115
103B-122
103B-166
ALLEN WRENCH
S 5 R
103B-95
D
C
B
A

FIGURE 2

PARTS FOR TYPE 103B MICROPHONE BOOM

LISTING OF PART NUMBERS SHOWN IN FIGURE 2

OUTSIDE PARTS NOT PICTURED ON FOLLOWING PAGES:

103B-115	Hand-grip casting with rubber grip
103B-122	Outside tube
103B-124	Deadening cord (7 foot)
103B-155	Sheave bracket liner
103B-166	Actuating rail
103B-95	Washer at rear end of rotating rail
S5R	Ball bearing at rear end of rotating rail

INSIDE PARTS NOT PICTURED ON FOLLOWING PAGES

103B-106	Inside tube
103B-118	Inside tube spring

OPERATING CORDS NOT PICTURED

(see stringing information in the instructions)

103B-167	Microphone rotating cord ($30^{1}/_{2}$ ft.)
103B-168	Actuating cord (2 ft.)
103B-169	Tube retracting cord (14 ft.)
103B-170	Tube extending cord (29 ft.)

PARTS FOR TYPE 103B MICROPHONE BOOM

103BD973


103B-79
103B-121
S - 3 - R
103B-119
103B-123
103B-85
(WITH FELT)
103B-198
103B-75
103B-116A
103B-99
103B-80A
103B-117
270
103B-81

FIGURE 3


103B-33
103B-19
103B-77
103B-46
103B-83
103B-78

FIGURE 4

PARTS FOR TYPE 103B MICROPHONE BOOM


103B-1
103B-22
103B-33
103B-5
103B-32
103B-23
103B-161
103B-6
103B-14
103B-157

FIGURE 5


103B-159
103B-129
103B-100
103B-160
103B-154
PAIR
103B-90
103B-127
103B-164
103B-125
103B-67A

FIGURE 6


103B-159
103B-129
103B-20A
PAIR
103B-160
103B-90
103B-127
103B-164
103B-125
103B-67A

FIGURE 7

PARTS FOR TYPE 103B MICROPHONE BOOM


103-68
103B-140
103B-141
103B-142
103B-54
103B-54A
103B-92
103-7
103B-50
103-67
500-20C
103B-49A
103B-51A
103-67A
126B-36
103B-49
170-51

FIGURE 8

PARTS FOR TYPE 103B MICROPHONE BOOM


103B-159
103B-162
103B-12
103B-152
103B-42
103B-27A
103B-131
103B-87
103B-16
103B-73
103B-164
103B-88
103B-70
103B-74
S-5-R

FIGURE 9


103B-158
103B-13
103B-130
103B-161
103B-136
103B-76
PAIR.
103B-160
103B-67
103B-128
103B-126
103B-164
103B-72
103B-135
103B-171
103B-68
103B-89
103B-153
103B-139

FIGURE 10

PARTS FOR TYPE 103B MICROPHONE BOOM

103BH973


103B-29
103B-36A
103B-34
103B-8
103B-152
103B-27A
103B-162
103B-12
103B-159
103-104
103B-136
103B-91
103B-164
103B-92
103B-15
103B-9
103B-161
103B-28
103B-35
103B-32
103B-2
103B-23
103B-5
103B-39
103B-69
103B-4
103B-38
103B-150
103B-58
103B-7
103B-171
103B-59
103B-37
103B-60

FIGURE 11

PARTS FOR TYPE 103B MICROPHONE BOOM


103B-30
103B-44
103B-47
103B-161
103B-18
103B-32A
103B-43A
103B-45
103B-153
103B-17A

FIGURE12
INSIDE


103B-27A
103B-151
103B-159
103B-156
103B-163
103B-162
103B-10
103B-24
103B-13
103B-153
103B-161
103B-158
103B-57
103B-138
103B-137
103B-93
103B-164
103B-69
103B-136
103B-3
103B-104
103B-11

FIGURE 13

PARTS FOR TYPE 103B MICROPHONE BOOM


CLAMP KNOB (126B-28)
126B-36
ELEVATING COLUMN
CAP SCREW
CLAMP KNOB (126B-71)

276

FIGURE 14

TYPE 103B MICROPHONE BOOM

TO PLACE IN SERVICE

1 - Mount boom, by means of its spud, on our Type 126B Perambulator or other support.

2 - Tighten quadrant lock screw (see Fig. 2).

3 - Attach microphone or equal weight.

4 - Attach counterweight box (see Fig. 2)

5 - With extension tube retracted, remove weights from inside counterweight box until the boom is slightly heavier to the rear.

6 - Check to see that all boom strings are in position (see instructions on re-stringing).

7 - Adjust tension of cords as follows:
    a - By means of operating handle, run extension tube out and back.
    b - If the extension tube hits against the rear of the boom, eliminate this noise by pulling the extension tube out slightly and moving the ring (see Fig. 1-R) backward to take up the required distance.
    c - Run the extension tube into a fully retracted position.
    d - Adjust cord tension at points E and G so that the cords are taut; this is done with the allen wrench provided (see Fig. 2). (Do not pull cords tight as a violin string).

8 - Wipe off tube on which counterweight carriage rolls.

9 - Mount your microphone cables as follows:
All references are to Figure 1 (side opposite operating handle).
    a - Clamp cable at B, allowing enough cable for rotating.
    b - Place cable over C pulley, wide part.
    c - Place cable over D pulley, wide part.
    d - Place cable over G pulley, wide part.
    e - Place cable over and around wide part of L (outer) pulley.
    f - Place cable under and around wide part of J pulley.
    g - Place cable over and around wide part of K (inner) pulley.
    h - Tie cable to same hole as microphone rotating cord - reverse side of J pulley.

10 - Microphone may be rotated to a position and held there by tightening knob (see Fig. 2). This knob also provides tension to the operator's taste in operation of the microphone rotating device.

TYPE 103B MICROPHONE BOOM

TO RE-STRING YOUR BOOM

Microphone Rotating Cord

103B-167 (30$^{1}/_{2}$ feet - no loops)

All references are to Figure 1 (side opposite operating handle)

1 - At A:
With inner extension tube retracted and counterweight carriage completely forward.
    a - Remove part from boom, take off cover.
    b - Hold in vise, rotate spring to clear sides of casting.
    c - Thread cord through hole from the outside.
    d - Make small knot in cord at the end and with no cord beyond the knot.
    e - Pull knot tight to inside of casting.
    f - Replace cover.
    g - Replace part on Boom.
    h - Wind cord 3 times around groove counter-clockwise looking at top.
2 - Place cord over narrow part of C pulley and under clip.
3 - Place cord over narrow part of D pulley.
4 - Place cord under E pulley.
5 - Place cord over narrow part of G pulley.
6 - Place cord over and around narrow part of L (outer) pulley.
7 - Place cord under and around narrow part of J pulley.
8 - Place cord over and around narrow part of K (inner) pulley.
9 - Tie cord to hook on reverse side of J pulley or tie cord in hole.

Actuating Cord

103B-168 (2 feet - no loops)

All references (unless otherwise stated) are to Figure 2 (Operating side)

1 - Thread cord through hole in M pulley and knot on outside.
2 - Place cord over top of M pulley.
3 - Place cord over top of H pulley (shown in Fig. 1).
4 - Place cord under and around F pulley (shown in Fig. 1).
5 - Pull cord through hole in F pulley and knot on outside.

Tube Retracting Cord

103B-169 (14 feet - loop on one end)

All references (unless otherwise stated) are to Figure 2 (Operating side)

1 - Take off nameplate A and casting B with wheel.
2 - Loosen ring R and pull forward (shown in Fig. 1).
3 - Push extension tube completely in, bringing the inside roller bracket in view at A.

TYPE 103B MICROPHONE BOOM

TO RE-STRING YOUR BOOM: Tube Retracting Cord (Continued)

4 - Remove Screw holding two small brass pieces at A.
5 - Place loop in groove formed by two brass pieces and replace them on roller bracket.
6 - Push inner tube forward about 2 inches beyond hole at B.
7 - Hold casting B with wheel up and hole C to right, or forward.
8 - Thread cord counter-clockwise and out hole C.
9 - Keeping cord tight over wheel, replace casting B on Boom.
10 - Place cord over and around H pulley.
11 - Place cord under and around D pulley.
12 - Wind cord counter-clockwise 3 times on F pulley keeping flat on wheel and winding front to back.
13 - Pull through hole and knot on outside of pulley.
14 - Push ring R (shown in Fig. 1) back, allow 5 inches of extension tube to show forward, and tighten ring screw.
15 - Adjust cord at G (see Paragraph 7 under "To place in service").
16 - Replace nameplate A.

Tube Extending Cord

103B-170 (29 feet - loop on one end)

All references are to Figure 2 (Operating side)

1 - At P:
    a - Remove sheave cover and wheel.
    b - Extend inside tube until screw at end of the tube shows in sheave hole.
    c - Attach cord loop under screw and washer with cord starting to the right, or forward.
    d - Push inside tube completely in.
    e - Hold sheave with hole O toward the left and the wheel up.
    f - Thread cord clockwise around the wheel and out the hole O.
    g - Keep cord tight so that it stays on the wheel.
    h - Replace sheave cover and wheel P on the Boom.
2 - At N with handle down:
    a - Start cord on the underside of the drum in groove 8, at the rear, or side of drum toward the boom.
    b - Wind cord clockwise around drum in the grooves toward the rear 4 times - this leaves 3 grooves at the rear not covered.
3 - Have counterweight carriage, containing F.H.J.K. full forward.
4 - Place cord over and around J pulley.

TO RE-STRING YOUR BOOM: Tube Extending Cord (Continued)

5 - Place cord under and around L pulley.

6 - Wind cord under and clockwise 3 times on K pulley keeping flat on wheel and winding front to back.

7 - Pull cord through hole in K pulley and knot on outside.

8 - Adjust cord at G (see Paragraph 7 under "To place in service").

MAINTENANCE AND NOISE PREVENTION

1 - The packing nut (Part 103B-22, Figure 5) screws down on an inner felt washer. Do not tighten too much or felt washer will produce a scraping noise.

2 - Keep extension tube clean to eliminate fouling the rollers.

3 - There are insulating washers on each side of the rubber rollers and pulleys. These washers should be kept well oiled with #10 oil. CAUTION: Do not allow oil on the rubber rollers.

4 - If the washers referred to in 3 above become worn, they should be replaced to prevent side play and noise.

5 - The quadrant (see part 103-68, Fig. 8) should be kept clean. Lubricate flat locking surfaces with dry graphite and quadrant swivel surface (top) with #10 oil in hole provided.

6 - Keep the cable drum (Part 103-7, Fig. 8) tight on its spindle by means of the screw just under the handle.

7 - There are bearings at each end of the actuating rail. These bearings are packed with grease at the factory and need no additional lubrication in service.

8 - If the extension tube slaps against the inside of the outer tube, run the extension tube full out, support it on both ends and pull down slightly in the center. This should be done very carefully to avoid bending too much.

9 - Keep the surface, on which the counterwweight carriage rides, clean.

10 - CAUTION: If the boom is not to be used for a period of time, the counterweight should be removed to prevent the weight from flattening the rubber rollers and producing a bumping noise.

11 - Keep the cords taut to prevent a slapping noise when the boom is extended and retracted. (See paragraph 7 under "To place in service").

12 - The rope wrapped spirally around the front part of the boom prevents transmission of noise. Do not pull too tight or it will not be effective. There is also a sound dampener on the inside consisting of a steel spring wire covered with fiber glass tubing.

13 - The rubber rollers have a center which is impregnated with graphite to make them self-lubricating. No oiling is necessary.

TYPE 103B MICROPHONE BOOM

PERAMBULATOR

TO PLACE IN SERVICE:

1 - Mount boom in perambulator socket.
2 - Tighten clamp knob 126B-28 (Fig. 14).
3 - Extend the rear wheels to obtain good stability when boom is being operated.
4 - Loosen capscrew and clamp knob 126B-71 (Fig 14).
5 - With the operator standing on the platform, raise the boom with the elevating wheel on the side of the circular front until the boom is at comfortable operating level.
6 - CAUTION - Tighten capscrew. If capscrew is loosened when platform is in raised position, the platform will drop.
7 - Now the platform and boom will rise together and the boom will always be in correct and comfortable operating height.
8 - When the boom and platform are at desired operating height, tighten clamp knob 126B-71 (Fig. 14).
9 - Repeat steps 4 thru 8 as required to obtain a comfortable operating height of boom above platform for any particular operator.

OPERATION:

1 - Rolling of the perambulator may be stopped by moving the tiller handle into upright position. This actuates a brake against the front tire.
2 - To retrace path of perambulator motion, lock front wheel at desired steering angle by tightening clamp knob on vertical spindle housing.
3 - The platform leaves are supported by pull-out bars.
4 - Rear wheels may be extended by loosening their locking knobs and pulling out the wheel and axle.
5 - Platform leaves may be dropped and rear wheels retracted for passage thru narrow door openings.

MAINTENANCE:

1 - Keep platform tubes clean and lubricated with dry graphite to prevent gumming of bearing surfaces.
2 - Occasionally oil elevating wheel shaft bearing (1 oil hole).
3 - Occasionally oil steering and locking mechanism (5 oil holes).
4 - Keep tires properly inflated (65 lbs. pressure).

75A8608

PARTS FOR TYPE 75
COMET LAMP BOOM


75-29
200-9C
200-41BP
75-26
75-21
75-25
75-30
406-65
410-104
75-13
75-52
500-16
200-9C
75-20A
75-4P17
75-4P16
75-48
75-42
75-4P17
75-4P15
75-47A
75-2P24
75-43
75-23
75-24
75-32
200-41BP
75-3P8
75-16
75-12
200-41BP
75-3P8
75-22
75-2P26
75-2P27
410-109
406-56
75-14
75-19
75-11
75-45
Accessory
75-6P9
75-37
75-6P9
75-34
75-6P14
75-6P13
75-6P12
75-33
75-33
75-23
75-6P10
75-15
75-6P10
75-36
Accessory
75-35
Accessory
75-18A

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 24 CENTURY HEAD


24-13
412-47
24-18
24-3P7
24-12
24-12
24-15P3
24-15P3
24-3
Complete Arm Assembly.
24-14
24-18
24-4P8
24-12
24-12
412-47
24-30
500-20C
24-4

PARTS FOR TYPE 324
CENTURY STAND

324A813


129-31
129-43
500-20CP
129-13
500-20CP
129-12
324-21
406-59
406-60A
324-2P26
324-20
324-2P27
555-56
324-2P19
324-2P20
324-2P21
410-109
324-23
324-22
324-2P21
324-2P23
406-54A
324-2P22
324-2P24
406-53
406-65
324-2P19
324-2P20
324-2P21
410-109
324-22
324-2P21
324-2P23
406-54A
324-2P22
324-2P24

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 3143
STANDARD CENTURY STAND


314-11P12
314-11P12
314-17
314-15
129-43
406-60
500-20CP
1859
500-20CP
314-13
314-26P4
314-3P7
314-29
314-27
314-21P4
314-25
314-22
314-16
314-18P18
314-14
314-12
314-19
314-20
314-3P9
314-30
314-3P8

3153A775

PARTS FOR TYPE 3153
MEDIUM CENTURY STAND


315-21P12
315-21P12
-32816
-315-27
129-13
500-20CP
315-25
500-20CP
26-22
26-21A
315-26
315-24
315-22
315-3P7
315-35P4
315-38
315-36
315-31P4
315-34
315-32
315-28P4
315-30
315-29
315-3P9
315-3P8
315-39

PARTS FOR TYPE 3144
CENTURY SINGLE ARM HEAD


314-38
314-35
314-7P6
314-7P5
314-40
314-7P8
314-40P2
314-36
314-33
314-37P4
314-37P4
314-7
Complete Arm
Assembly.
One required.
314-39
314-35
314-6P7
314-40
314-6P6
314-33
314-6P9
314-36
314-40P2
314-32
500-20C
314-6

Mole-Richardson Co.

PARTS FOR TYPE 3154
MEDIUM CENTURY SINGLE ARM HEAD


314-38
315-7P6
315-7P8
314-36
314-35
315-7P5
314-40
314-40P2
314-33
315-41P4
315-41P4
315-7
Complete Arm
Assembly.
One required.
315-40
314-35
314-6P7
314-40
314-33
314-6P6
314-6P9
314-36
314-40P2
314-32
500-20C
314-6

Mole-Richardson Co.

Tel. (323) 851-0111 Fax. (323) 851-5593 E-mail: info@mole.com Internet: http://www.mole.com 937 N. Sycamore Ave., Hollywood, California 90038-2384 U.S.A.

PARTS FOR TYPE 3145
CENTURY DOUBLE ARM HEAD


314-7P6
314-7P8
314-36
314-33
314-40
314-35
314-38
314-7P5
314-40P2
314-37P4
314-37P4
314-7
Complete Arm Assembly. Two required.
314-39
314-35
314-6P7
314-40
314-6P6
314-33
314-6P9
314-40P2
314-36
314-32
500-20C
314-6

PARTS FOR TYPE 3155
MEDIUM CENTURY DOUBLE ARM HEAD


314-38
314-35
315-7P6
315-7P8
314-36
315-7P5
314-40
314-40P2
314-33
315-41P4
315-41P4
315-7
Complete Arm
Assembly.
Two required.
315-40
314-35
314-6P7
314-40
314-33
314-6P6
314-6P9
314-40P2
314-36
314-32
500-20C
314-6

3166A777

PARTS FOR TYPE 3166
CLAMP HEAD


316-31
316-35
316-9
316-6P8
316-6P9
316-6P7
316-32
316-40
316-10P4
316-10P4
316-9P3
316-34
316-10

PARTS FOR TYPE 50 HALF STAGE PLUG (NOT FUSED)


500-72
500-359
500-360
500-99AP9
500-99AP10
500-99AP19
500-103A
500-99AP9
500-99AP7
500-55C
500-99AP7
500-101
500-102A
500-99AP7
500-55C
500-99AP7
500-99AP8
500-103A
500-360
500-99AP19
500-99AP8
500-99AP10
500-359
500-72
MODEL 50
20A 250V

HARDWARE & TERMINALS FOR TYPE 50 HALF STAGE PLUG		
DESCRIPTION	NO. REQ.	ORDERING INFORMATION
COVER SCREWS	4	MACH. SCR. FLAT HD. 6-32 x 3/8″ LNG. ST.-CAD. PL.
TERMINAL SCREWS	2	SEMS EXT PAN HD. 6-32 x 3/16″ LNG. ST.-CAD. PL.
CABLE CLAMP SCREWS	2	MACH. SCR. RND. HD. 8-32 X 7/16″ LNG. ST.-CAD. PL.
CABLE CLAMP NUTS	2	HEX. NUT 8-32 M.S. ST.-CAD. PL.
TERMINALS		
FOR NO. 12 A.W.G. WIRE	2	NO. C10-6
FOR NO. 14 A.W.G. WIRE	2	NO. B14-6
FOR NO. 16 A.W.G. WIRE	2	NO. B14-6
FOR NO. 18 A.W.G. WIRE	2	NO. A18-6

50F2A886

PARTS FOR TYPE 50F2
HALF STAGE PLUG (FUSED)


500-72
500-359
500-100P12
500-360
500-100P8
500-100P11
500-100P7
500-104
500-100P11
500-55C
500-106
500-100P9
500-100P9
500-101
MODEL 50F2
20A 125V
USE FUSE
30A 125V
500-102
500-100P9
500-106
500-100P9
500-55C
500-100P10
500-104
500-360
500-100P21
500-100P10
500-100P8
500-359
500-100P12
500-72

HARDWARE & TERMINALS FOR TYPE 50F2 HALF STAGE PLUG		
DESCRIPTION	NO. REQ.	ORDERING INFORMATION
COVER SCREWS	4	MACH. SCR. FLAT HD. 6-32 x 3/8″ LNG. ST.-CAD. PL.
TERMINAL SCREWS	2	SEMS EXT PAN HD. 6-32 x 3/16″ LNG. ST.-CAD. PL.
CABLE CLAMP SCREWS	2	MACH. SCR. RND. HD. 8-32 X 7/16″ LNG. ST.-CAD. PL.
CABLE CLAMP NUTS	2	HEX. NUT 8-32 M.S. ST.-CAD. PL.
TERMINALS		
FOR NO. 12 A.W.G. WIRE	2	NO. C10-6
FOR NO. 14 A.W.G. WIRE	2	NO. B14-6
FOR NO. 16 A.W.G. WIRE	2	NO. B14-6
FOR NO. 18 A.W.G. WIRE	2	NO. A18-6

100AA796

PARTS FOR TYPE 100A FULL STAGE PLUG


500-79
500-79
500-109
500-79
500-79
500-112P8
500-108
500-112P9
500-55C
500-110
500-111
500-112P7
500-112P9
500-55C
500-112P12
500-112P13
500-112P10
500-108
500-112P8
500-112P14
500-109
500-112P14
500-112P13
500-112P10
500-112P12

HARDWARE & TERMINALS FOR TYPE 100A FULL STAGE PLUG			
DESCRIPTION	NO. REQ.	ORDERING INFORMATION	
TERMINAL SCREWS	2	MACH. SCR. RND. HD. 10-24 x 5/16″ LNG.	BRASS
TERMINAL NUTS	2	HEX. NUT 10-24 M.S.	BRASS
FRONT COVER SCREWS	1	MACH. SCR.FLAT HD. 10-24 x 1/2″ LNG.	ST.-CAD. PL.
REAR COVER SCREWS	2	MACH. SCR. FLAT HD. 10-24 x 1″ LNG.	ST.-CAD. PL.
CABLE CLAMP TELESCOPING NUT	4	500-79	
CABLE CLAMP SCREWS			
FOR 5/8″ TO 3/4″ O.D. CABLE	2	MACH. SCR. FLAT HD. 10-24 x 3/8″ LNG.	ST.-CAD. PL.
FOR 3/4″ TO 7/8″ O.D. CABLE	2	MACH. SCR. FLAT HD. 10-24 x 1/2″ LNG.	ST.-CAD. PL.
FOR 7/8″ TO 1″ O.D. CABLE	2	MACH.SCR. FLAT HD. 10-24 x 5/8″ LNG.	ST.-CAD. PL.
TERMINALS			
FOR NO. 10 A.W.G. WIRE	2	NO. C10-10	
FOR NO. 8 A.W.G. WIRE	2	NO. 33460	
FOR NO. 6 A.W.G. WIRE	2	NO. E6-10	
FOR NO. 4 A.W.G. WIRE	2	NO. F4-10	